

K2X

MultiTool




en




kbgo.to/supe







DE Die technischen Darstellungen und Maßangaben – auch bei Abbildungen und Zeichnungen – sind unverbindlich. Konstruktionsverbesserungen sind vorbehalten! **EN** Technical information and stated dimensions (including in illustrations and drawings) must not be regarded as binding. Design subject to improvement without notice! **FR** Les visuels techniques et dimensions – y compris les schémas et les illustrations – ne sont pas contractuelles. Sous réserve d'évolutions techniques! **IT** Le rappresentazioni tecniche e le indicazioni delle dimensioni – anche nelle figure e nei disegni – non sono vincolanti. Con riserva di miglioramenti di progettazione! **ES** Las imágenes técnicas y las indicaciones de medidas – también en imágenes y dibujos – no son vinculantes. Queda reservado el derecho de realizar mejoras en el diseño! **PT** Representações técnicas e dimensões – mesmo em ilustrações e desenhos – não são vinculativas. Reservado o direito a melhorias construtivas! **HE** כל התרשימים הטכניים והמידות – אף לאבי אירורים ותכניות – הנמ' בLATI מחייבים. **FI** Tekniset piirrokset ja mitat – myös kuvissa ja piirroksissa olevat – ovat sitoumukseltaa. Oikeus rakennetta parantaviin muutoksiin pidätetään! **DA** De tekniske illustrationer og målangivelser - også på illustrationer og tegninger - er ikke bindende. Forbehold for designforbedringer! **CZ** Technické popisy a rozměry, jakož i obrázky a výkresy, jsou nezávazné. Vyhrazujeme si právo na změny konstrukce! **PL** Prezentacje techniczne i wymiary – także na ilustracjach i rysunkach – nie są wiążące. Udoskonalenia konstrukcyjne są zastrzeżone! **RU** Иллюстрации технических деталей и указанные размеры, в том числе на рисунках и чертежах, являются ориентировочными. Компания оставляет за собой право на усовершенствование конструкции! **TR** Teknik sunum ve ölçü bilgileri (resim ve çizimlerde de) yasal olarak bağlayıcı değildir. Yapısal geliştirmeler yapma hakkı saklıdır! **BG** Техническото представяне и размерите, включително при изображенията и чертежите, са необвързвачи. Запазваме си правото на конструктивни подобрения! **HU** A műszaki ábrázolások és méretadatok – ábráknál és rajzoknál sem – nem kötelező érvényűek. A konstrukciós javítások joga fenntartva! **SR** Tehničke ilustracije i dimenzije - uključujući ilustracije i crteže - nisu obavezujući. Dizajn poboljšanja su rezervisana! **EL** Τα τεχνικά σχήματα και οι διαστάσεις – ακόμα και σε απεικονίσεις και σχέδια – δεν είναι δεσμευτικά. Με την επιφύλαξη τεχνικών βελτιώσεων! **AR** الرسم التوضيحية والأبعاد الفنية - ليس ذلك الرسوم التوضيحية والرسومات - ليست إلزامية. الحق محفوظ في إجراء تحسينات هيكلية! **JA** が生みにくさが高じれ **ZH** 技术说明和规格，包括插图和图纸均不具约束力。保留改进设计的权利！



en



Marking a 90° angle


The K2X MultiTool is primarily a measuring tool. Please note that the 90° angle function can only be guaranteed if the movable stop is firmly screwed to the ruler.

To do this, please turn the knurled screw clockwise until the movable stop is fixed tightly!


Attention: When using the spring clamp, protect the surfaces from scratches!




The most important functions



Finding the center
in the carcase



Finding the center
on the front panel



Finding the center
on the top panel




Marking 90° angle
and depth measure-
ment




Marking a spacing
of 32 mm



Marking measure-
ments for pull-out
runners



Measuring the front
panel overlap



Marking measure-
ments for handles



The K2X MultiTool rulers

The rulers come in two different lengths:

440 mm and 600 mm esp. 15,75 inch and 23,62 inch.

The long ruler is ideal for deep, wide cabinets and front panels.

The shorter ruler is ideal for short, narrow cabinets and front panels.

en

Movable stop

Each ruler has one movable stop.

- It has two different scales on the longitudinal edges (see fig.10).
- Spring clamp (see fig.12a-14b)


**3**

Inserting the movable stop

The movable stop is inserted into the ruler from below. First, the knurled screw is loosened by turning it until the slot nut can move freely on the knurled screw (approx. 5 mm gap between slot nut and movable stop).

Please note: The slot nut must remain on the thread and must not be unscrewed. Then the slot nut with the stop is inserted into the slot through the opening of the profile in the bottom side so that the stop can be moved in the slot.


The movable stop is to be fixed in the desired position with the knurled screw.

4

Moveable stop


You can move the stop anywhere on the ruler after twisting the knurled screw to loosen it.

This allows measurements to be taken from almost any position on the measuring scale.


5

Fixing and releasing the stop

Loosen the knurled screw to move the stop anywhere on the ruler. Twist the screw to fix the stop in the desired position.




To guarantee a 90° angle between the stop and the measuring ruler, the knurled screw must be fixed. The stop must not be moveable any more!





Finding the center in the carcase

To quickly find the center of a bottom in a carcase, the K2X MultiTool incl. stop is placed with the labeled side on the bottom. The movable stop must not cover the marking hole (see fig. 6a).



Now the K2X MultiTool is turned diagonally until both green end caps with the rounded sides rest against the cabinet walls on the right and left. The marking point in the center of the measuring ruler is now exactly in the center of the inner cabinet width. Now the center can be marked with a sharp pencil.




By means of the measuring ruler and stop, the marked cabinet center can now be transferred to the cabinet front edge.




Finding the center on a front panel

To quickly find the center on a front panel, place the K2X MultiTool incl. stop with the labeled side on the front panel.



The stop must not cover the marking hole.




The K2X MultiTool is now turned diagonally until both black stop pins are in contact with the outer edges of the front panel. The marking point in the center of the ruler is now exactly in the center of the front panel.

Now the center can be marked with a sharp pencil.




By means of the measuring ruler and stop, the marked front center can now be transferred to the top or bottom edge of the panel.



8 Finding the center on the top panel

To quickly find the center on the top panel in a cabinet, the K2X MultiTool incl. stop is held with the labeled side against the top panel.

The stop must not cover the marking hole.





Now turn the K2X MultiTool diagonally until both green end caps with the rounded sides are in contact with the cabinet walls on the right and left.

The marking point in the center of the measuring ruler is now exactly in the center of the inner cabinet width.

Now the center can be marked with a sharp pencil.


To make work easier, the K2X MultiTool can be attached to the top panel with the spring clamp (see fig. 8b).



Using the measuring ruler and stop, the marked cabinet center can now be transferred to the cabinet front edge.



Attention: When using the spring clamp, protect the surfaces from scratches!




Marking 90° angle and depth measurement

To mark a depth dimension on the cabinet side in a cabinet, the K2X MultiTool incl. stop is placed against the cabinet side. At the same time, the stop rests against the cabinet edge.


Please note that the 90° angle function can only be guaranteed if the stop is firmly screwed to the measuring ruler. To do this, please turn the knurled screw until the movable stop no longer moves!


To make work easier, the K2X MultiTool can be fastened to the cabinet side with the spring clamp (see fig. 14a/14b).



The measuring ruler and the stop are so wide that this tool can be used to mark very easily and exactly 32 mm distances .


This is particularly helpful when marking drilling points for drawer slides and hinges.





Two measuring ranges


The stop has two scales and can be inserted into the ruler rotated by 180° – depending on whether you want to measure from the centre of the ruler or from one edge.



Measuring the front panel overlap

The K2X MultiTool has a special scale that allows the differential dimension Y for the front overlap to be preset (see fig. 11/11a).

For this purpose, the stop can be shifted visible in a cut-out of up to ± 25 mm.



en

**12a**

Clamp form and function

Spring clamp for fixing the K2X MultiTool to thinner carcase sides.

12b

Spring clamp for fixing the K2X MultiTool to thicker/double-sided cabinet sides.

13

Fixing tool with the clamp

By turning the knurled screw, you can loosen the spring clamp and then bring it into the desired position.

Turn the knurled screw clockwise to fix the spring clamp again.

14a**14b**

Attention: When using the spring clamp, protect the surfaces from scratches!