

#### UNDERWATER MP3 PLAYER

# FAQ'S

#### CHARGING

- a. Charge your unit fully before first use
- b. Device will turn off automatically when battery is depleted
- c. Low Battery (blinking RED light)
- d. Charging (blinking GREEN light)
- e. Fully Charged (solid GREEN light)

#### **HOW DO I PLAY MUSIC?**

- a. On: Press and Hold for 3 seconds, solid GREEN light
- b. Off: Press and Hold for 3 seconds, blinking GREEN light
- c. Play: Single Press, GREEN light blinks once every 3 seconds
- d. Pause: Single Press, GREEN light will blink twice every 3 seconds
- e. Advance: Single Press plays next song
- f. Volume Down: Press and Hold to decrease volume. blinking GREEN light
- g. Replay Current Song: Single Press to play current song from beginning
- h. Backward: Double Press to play previous song(s)
- i. Volume Up: Press and Hold to increase volume, blinking GREEN light
- j. Random Play On: Press and Hold for 3 seconds, blinking GREEN light
- k. Random Play Off: Press and Hold for 3 seconds, solid GREEN light

## HOW DO YOU CONVERT SONGS TO MAKE THEM COMPATIBLE FOR THE DUO?

- Drag and drop all songs from the FINIS drive to iTunes
- Add the column KIND to iTunes, this displays the song format
  - o To add a column, right click over a column name. A drop-down menu will appear, check KIND
- If the song is in improper format, right click the song to display a drop-down menu
  - o Click "create MP3 version", this creates another copy of the song in a MP3 format that is compatible with FINIS devices
- Once all songs are in the proper format clear FINIS drive and drag new MP3 files to the FINIS drive
- IF "Create AAC encoder" is displaying instead of "Create MP3 version", on a MAC, please follow the instructions below:
  - o Click the "iTunes" label next to the apple icon located in the upper left corner of the screen. A drop-down menu will appear, select "Preferences..."
  - o Under the General tab, click "Import Settings"
  - o Under Import Using: change "AAC Encoder" to "MP3 Encoder"
  - o Once the settings are changed, please proceed with the above directions to convert improper formats to MP3
- IF "Create AAC encoder" is displaying instead of "Create MP3 version", on a PC, please follow the instructions below:
  - o Click the "half shaded box" located in the upper left corner of the screen. A drop-down menu will appear, select "Preferences..."
  - o Under the General tab, click "Import Settings"
  - o Under Import Using: change "AAC Encoder" to "MP3 Encoder"
  - o Once the settings are changed, please proceed with the above directions to convert improper formats to MP3

## FINIS, Inc.

FINISinc.com **USA** 925.454.0111 | **EU** +359 2 936 86 36





#### UNDERWATER MP3 PLAYER

## FAQ'S

#### WHY IS MY DUO NOT PLAYING MUSIC AFTER I TRANSFERRED SONGS?

There may have been a non-compatible song downloaded on the device. Please be sure all songs are converted to MP3 format before uploading to the device.

#### WHAT UNSUPPORTED AUDIO FILES CANNOT BE UPLOADED ON THE DUO?

- Protected: MP3, AAC (or purchased) and WMA are not supported or playable.
- Books downloaded from Audible are not supported or playable.
- MP3 files need to be 1000 KBS or higher. Anything lower is considered a short cut file.

### **HOW DO I CARE FOR MY UNIT?**

- a. Rinse Duo with fresh water after every use.
- b. Pat dry and store in safe, cool, dry environment.
- c. Do not place Duo in direct sunlight to dry. This may cause damage to the casing, battery and charging pins.
- d. Do not use sharp objects, such as fingernails, to depress buttons as this could puncture surface and lead to water damage.
- e. Duo is waterproof to 10ft or 3m and can be safely used in swimming pools, lakes, oceans or any fresh/salt bodies of water
- f. Do not attempt to charge or connect while wet, USB Magnetic Dock is not waterproof.
- g. Recommended: Keep the charging gold connectors clean by using a toothbrush and rubbing alcohol to prevent residue build-up.

## IF YOU ARE EXPERIENCING ANY OF THE PROBLEMS BELOW, YOUR DEVICE MIGHT NEED TO BE RESET.

- Device not recognized
- Device not turning on
- Green light not appearing
- Device stuck on pause

To reset the device: Connect the device to the computer, press and hold the Random Play button for 25-40 seconds, then release.

