

Disassembly Instructions - Dynorbital EXTREME

Models: All

Important: Disconnect sander from the air supply.


Notice: Use these instructions along with the tool manual. To avoid damage, use the **special repair tools** designed for motor disassembly and assembly. Position **57092 Repair Collar** around the housing. Fasten sander in vise with sanding pad facing up. Do not over tighten sander in vise. Use **50679 Wrench (26 mm)** to hold the balancer shaft stationary.



To remove sanding pad, turn counterclockwise.




Motor Disassembly:




1. Use **56058 Lock Ring Wrench** to remove **59058 Lock Ring**.
 - Turn counterclockwise.




2. Remove motor from housing.
 - Remove **01024** O-Ring from **59133** Cylinder Sleeve Adapter.




3. Fasten **96346 Bearing Separator (2")** around **59134 Cylinder Sleeve**. Place bearing separator and motor in **96232 Arbor Press (#2)** with counterweight pointing down.
 - Use arbor press and 5/16" or 8 mm diameter flat-end drive punch to push shaft out of **58368 Bearing**.




4. Use **96214 Bearing Removal Tool** to remove **58368 Bearing** from **59332 Rear Bearing Plate**.



5. Remove vanes, rotor and key.



6. Use bearing separator and arbor press to remove the front bearing plate and seal.



7. Fasten bearing separator between **58368** Bearing and the counterweight.
 - Place bearing separator in arbor press with counterweight pointing down.
 - Push shaft balancer from **58368** Bearing.


Motor disassembly completed.

Balancer Shaft and Bearing Disassembly:

1. Fasten counterweight in vise with hex of **57069** Balancer Shaft pointing up.
 - Use a thin slot-blade screwdriver as a pick to remove **95630** Snap Ring.
(Next three views.)









2. To break adhesive bond, use two, large slot-blade screwdrivers to pry out balancer shaft and bearing. **Notice:** If necessary, use a HEAT GUN to warm counterweight to soften adhesive.




3. Use **56056 Bearing Puller** to remove balancer shaft and **56052 Bearing**.



4. Fasten bearing separator between **56052** Bearing and hex end of balancer shaft.



5. Place bearing separator and balancer shaft in arbor press with hex end pointing down.
 - Use the arbor press to break the adhesive bond.



6. Use a 5/16" or 8 mm diameter flat-end drive punch as a press tool to push balancer shaft out of **56052** Bearing.



Balancer shaft and bearing disassembly completed.


Clean and inspect parts before assembling.

Assembly Instructions - Dynorbital EXTREME

Balancer Shaft and Bearing Assembly:




1. Install **95630** Snap Ring onto **59084** Seal.




2. Install **59084** Seal and **95630** Snap Ring onto **57069** Balancer Shaft.
Notice: Position flat side of seal toward **56052** Bearing.
 - Apply a small amount of Loctite #271 or equivalent to outside diameter of balancer shaft.



3. Use small diameter of **57091 Bearing Press Tool** and arbor press to install **56052 Bearing**. **Notice:** Position sealed side of bearing toward **59084 Seal**.
 - Press bearing to step on shaft.




4. Apply a small amount of Loctite #271 or equivalent to outside diameter of **56052** Bearing.
 - Install balancer shaft with bearing into shaft balancer.




5. Use a thin slot-blade screwdriver to compress and install **95630** Snap Ring into groove of shaft balancer.

Balancer shaft and bearing assembly completed.


Motor Assembly:




1. Install **59083** Felt Washer into **59057** Front Bearing Seal.
 - Install onto shaft balancer.




2. Use small diameter of **57091 Bearing Press Tool** and arbor press to install **58368 Bearing** onto shaft balancer.




3. Use large diameter end of **57091 Bearing Press Tool**, and arbor press to install **59333 Front Bearing Plate**.




4. Carefully fit plate to the bearing, felt washer and front bearing seal. Notice: The felt washer should be completely retained in the front bearing seal.




5. Install **56047** Key and rotor onto shaft balancer.




6. Apply **95842** Dynabrade Air Lube 10W/NR or equivalent to vanes and install.




7. Install **95529** O-Ring into **59133** Cylinder Sleeve Adapter.
 - Line-up tab on cylinder sleeve adapter with small slot in **59134** Cylinder Sleeve.



8. Install **59134** Cylinder Sleeve and **59133** Cylinder Sleeve Adapter so that short pins fit into front bearing plate.



9. Use **RAISED OUTSIDE DIAMETER** of **96239 Bearing Press Tool** and arbor press to install **58368 Bearing** into **59332 Rear Bearing Plate**.



10. Use **RAISED INSIDE DIAMETER** of **96239 Bearing Press Tool** and arbor press to install bearing and plate onto shaft balancer.
 - **Notice:** Carefully press bearing/plate down until it **just touches the cylinder.** This will produce a close fit between the bearing plates and cylinder sleeve.
 - Apply oil to **01024 O-Ring** and install into **59133 Cylinder Sleeve Adapter**.



11. Install **59058** Lock Ring over counterweight.
 - Sight line-up pin with notch inside housing. Keep finger pressure against lock ring and install motor.



12. Place **57092 Repair Collar** around housing. Fasten sander in vise with counterweight pointing up. **Notice:** Do not over tighten sander in vise or it will be difficult to install **59058 Lock Ring**.
- Use **56058 Lock Ring Wrench** to tighten lock ring. Turn clockwise.
 - Torque to 23 N•m/~200 lbs. in.

Motor assembly completed.

To install sanding pad, use **50679 Wrench** (26 mm.) to hold balancer shaft stationary. Turn pad clockwise.

IMPORTANT:

To verify the correct RPM and tool performance, follow instructions on page 2 of tool manual. Refer to: "Maintenance Schedule - Every 20 Hours/Once a Week - First Bullet:
• Measure RPM" and follow the instructions.

Vacuum & Exhaust Assemblies:

To identify vacuum and exhaust components, refer to exploded view and parts list found in tool manual.