

Progress order

- 1. Build tube socket on the chassis
- 2. Spread out the wing of tube retainer-1
- 3. Insert vacuum tube into the socket