



## Installation Instructions For 3080 Pilaster Shoes.

1. Locate and drill two 3/4" holes into floor for pilaster shoe anchor bolts.
2. Insert lead anchors into holes.
3. Adjust 3080 pilaster shoes for snug fit on pilaster. Tighten into place.
4. Drill a 3/8" x 1-1/2" hole into bottom of pilaster.
5. Insert T-nut into 3/8" drilled hole.
6. Screw hex bolt (with nut and washer) into T-nut.
7. Place pilaster into position. Level as needed. Tighten hex nut.
8. Cut spacer plate to size as needed.
9. Insert spacer plate.
10. Drill two horizontal holes through spacer plate and pilaster.
11. Insert and tighten thru bolts.

