NOTES:

- 1. FOR FLOATING WOOD FLOORS ONLY:

 - a) Remove flange from floor anchor (4, FP-89) before installation.
 b) Refer to FP-100 instuctions for details on installation of floor anchor and brass cover plate (5, FAC-101B).
- 2. FOR ALL OTHER FLOOR TYPES:
 - a) Brass cover plate (5, FAC-101B) is only necessary for installations with floating wood floors. May be discarded when installing kit in all other floor types.
 b) Refer to FP-89 instuctions for details on installation of floor anchor.



				CHAIN		MODEL NUMBER: CHECKED BY: PBELKIT WVB			
2	2	HM242	N/A	SHACKLES GALV FORGED 1/4" WITH					WVB
				SCRW PIN	Jeyppo"	PRODUCT NAME:			
3	1	HB202	N/A	1/2"-13 x 1-1/2" EYEBOLT STEEL W/	Aug 1888	PBEL ANCHOR KIT FOR ALL FLOOR			
				SHLDR	976 Hartford Turnpike Waterford, CT 06385 USA	TYPES - SUPPLIED WITH PBEL96			
4	1	FP-89	N/A	FLOOR ANCHOR	(800)243-0533 Fax: (800)988-3363	DATE:	REV:	DRAWN BY:	SHEET:
5	1	FAC-101B	N/A	BRASS COVER PLATE ASSEMBLY	www.jaypro.com	3/6/2012	-	Moune T.	1 OF 1



