REMOVABLE PITCHERS PLATE

Installation Instructions Models: PR-418 & PR-424

- 1. Excavate hole at location required for your distance. (24" long x 12" wide x 12" deep)
- 2. Establish block to allow top of anchor 2" below top of mound.
- 3. Fill hole with stone to bottom of anchor.
- 4. Pour concrete to within 1/2" of top of anchor. 2-1/2" below top of mound. Allow to cure.
- 5. Fill void with mound clay allowing for taper to openings of anchor.

MAINTENANCE: Keep ground anchors covered with BB-Plugs when not in use to prevent dirt from getting into the anchor. Remove any dirt that might obstruct the base from entering the ground anchor.

