



NOTE:

1) TIGHTEN THE SCREW STUD SNUGLY, BUT DO NOT OVERTIGHTEN IT. THIS MAY STRIP THE THREADS IN THE SNUG PLUG.

2) INSTALLATION IS THE SAME FOR THE CROSSBAR AND UPRIGHTS.

3) THE NET TIE CLIPS INSTALLED INTO THE LEFT AND RIGHT UPRIGHTS ARE TO FACE TOWARD THE INSIDE OF THE UNIT. (NIPPLE-SIDE)

IMPORTANT:

DUE TO EXPECTED VARIATIONS IN SCREW HEAD SIZE, SOME OF THE SCREWS INCLUDED MAY NOT EASILY FIT THRU THE NET TIE CLIP. FOR YOUR CONVENIENCE, APPROXIMATELY 30 EXTRA SCREWS HAVE BEEN INCLUDED SO THAT THE OVERSIZE SCREWS MAY BE DISCARDED. FOR EASE OF ASSEMBLY, TEST FIT SCREW INTO CLIP PRIOR TO FASTENING TO GOAL.

Jaypro Sports

976 Hartford Turnpike
 Waterford, CT 06385 USA
 (800)243-0533
 (800)988-3363 Fax
 www.jaypro.com

MODEL NO.:
SNT-180

PRODUCT NAME:
 INSTALLATION
 OF NET CLIPS

DRAWN BY: JAC

EFFECTIVE DATE:
 6-2-03