



APPLICATION INSTRUCTIONS FOR BA10/BA10A REPLACEMENT SHOOTER'S SQUARE

NOTE: If removal of old shooter square is required, soak existing shooter square with windex/dish soap and water solution. Allow 10 - 30 min before attempting to remove existing shooter square.

1. Mark off your board with a base line. In all cases the new shooter's square will be applied to the front side of the board.
2. Turn shooter square over masking tape side down, pull on a corner to remove the backing sheet from the mask, now you will have the sticky side up showing.
3. Clean the area where the replacement square will be positioned.
NOTE: on the BA10A for acrylic backboards the width of the lines are slightly wider than the original lines to allow you to hide any irregular edges of the original square.
4. Use a Windex type product and spray the backboard to wet the surface. Also spray the adhesive side of the shooting square.
5. Flip the shooter's square over and slide into position.
6. Use a credit card or similar object to squeegee out the water starting from the center. Use the card in a circular type motion to push the water out from under the masking tape.
7. Allow the square to set. The length of time required depends on the temperature.
8. Remove the mask by pulling diagonally across the square from a corner slowly. No air bubble should be present, however if you find any go back over the area with your card to force them out before the square is allowed to gain its final setting position.