Model # <u>NO FAIL NETLOCK</u> Date: <u>04.29.98</u> Ref # <u>900108</u> Rev. J

NET INSTALLATION INSTRUCTIONS FOR NO-FAIL NETLOCK SYSTEMS

- 1. Slip twisted loop (VIEW A) thru no-fail netlock cut-out from the inside of the rim outward (VIEW C).
- 2. Wrap twisted loop around bottom of no-fail netlock band and back through the cut-out a second time.
- 3. Connect loop over the "T" shaped hook (VIEW B).
- 4. Pull not tight to assure that the not appears like the illustration in (VIEW C).
- 5. Failure to attach net in this manner increases the likelihood that the net will not stay attached during play.

