

Installation Instructions for P-GRV-406

1. Turn tip of string post until it clicks into place. This aligns string post holes.
2. **Note string hole is off center.** Turn knob to rotate post until string hole is positioned away from knob. Thread string up through bottom of hole and pull firmly. See drawing.
3. Turn to begin tuning. **At first, only inner “Locking Cam” is turning, securely locking the string.** Once the string is locked, outer post will turn.
4. Bring string to pitch.

