Yellow Jackets®

Tube Converter



Includes NOS 6AQ5 Tubes Handmade in the U.S.A.

Yellow Jackets® Tube Converter

Designed by R



Includes NOS 6AQ5 Tubes Handmade in the U.S.A.

Yellow Jackets®

Tube Converter

Yellow Jackets® **Tube Converter**



Designed by 1111)

Yellow Jackets® Tube Converter





Includes NOS 6AQ5 Tubes Handmade in the U.S.A.

Yellow Jackets®

- Converts most audio amplifiers with 6L6, EL34. 7027, or 6V6 tubes to 6AQ5s without modification or rebiasing.
- · Converts from Class AB to Class A operation!
- · Lowers the overall power in your amplifier.
- · Safe for all common amplifiers and transformers.
- · One year limited warranty on converter.
- "The next best thing to getting yourself a new amp. - Guitar World Magazine
- · "Increase amplifier flexibility"
- Guitar Player Magazine



- · Converts most audio amplifiers with 6L6. EL34. 7027, or 6V6 tubes to 6AQ5s without modification or rebiasing
- · Converts from Class AB to Class A operation!
- · Lowers the overall power in your amplifier.
- · Safe for all common amplifiers and transformers.
- · One year limited warranty on converter.
- "The next best thing to getting yourself a new amp. - Guitar World Magazine
- · "Increase amplifier flexibility"
- Guitar Player Magazine

Yellow Jackets®

- Converts most audio amplifiers with 6L6, EL34. 7027, or 6V6 tubes to 6AQ5s without modification or rebiasing
- Converts from Class AB to Class A operation!
- · Lowers the overall power in your amplifier.
- Safe for all common amplifiers and transformers.
- · One year limited warranty on converter. "The next best thing to getting yourself a new amp.
- Guitar World Magazine
- · "Increase amplifier flexibility" - Guitar Player Magazine

Yellow Jackets®

- Converts most audio amplifiers with 6L6_FL34 7027, or 6V6 tubes to 6AQ5s without modification or rebiasing
- · Converts from Class AB to Class A operation!
- · Lowers the overall power in your amplifier. Safe for all common amplifiers and transformers.
- · One year limited warranty on converter.
- . "The next best thing to getting yourself a new amp. - Guitar World Magazine
- · "Increase amplifier flexibility"
- Guitar Player Magazine

Yellow Jackets®

- Converts most audio amplifiers with 6L6, EL34. 7027, or 6V6 tubes to 6AQ5s without modification or rebiasing
- . Converts from Class AB to Class A operation! · Lowers the overall power in your amplifier.
- Safe for all common amplifiers and transformers.
- · One year limited warranty on converter.
- · "The next best thing to getting yourself a new amp." - Guitar World Magazine
- · "Increase amplifier flexibility"
- Guitar Player Magazine



CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789 info@yellowjacketstc.com www.yellowjacketstc.com







Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789 info@yellowjacketstc.com www.yellowjacketstc.com

6221S. Maple Avenue



CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ, 85283 Phone: 480.755.4712 Fax: 800.706.6789

info@yellowjacketstc.com www.yellowjacketstc.com



CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789

info@yellowjacketstc.com www.yellowjacketstc.com

Thank You!

Thank you for buying our Yellow Jackets® converter! It will provide you with years of service, assuming that you replace the tubes when they are worn, and will also give you a much greater variety of sounds from your amplifiers than you have ever experienced before.

How to Install Yellow Jackets®:

1. With your amplifier cold and turned off, remove the 6L6, EL34, 7027, or 6V6 tube from its socket. (Use a towel to protect your hands if the tubes are hot).

- 2. Place the Yellow Jackets® converter in the tube socket, 2. Place the Yellow Jackets® converter in the tube socket, screw the ground wire under the tube socket mounting screw (to provide an adequate ground connection), and install a 6AQ5 tube into the Yellow Jackets® converter. Make sure that all pins are properly aligned and do not force anything. It should all go smoothly if the tube pins are properly aligned.
- 3. Turn the amp on, let it warm up, and play. Your amp 3. Turn the amp on, let it warm up, and play. Your amp is now running in Class A mode with a 6AQ5 output tube.

You do not have to adjust the bias of your amplifier as the Yellow Jackets® converters themselves create their own cathode bias circuit, ignoring the bias setting in your amp. This also means that when you put your old tubes back into the amplifier, your bias will be set just as you left it.

Please allow time for the Yellow Jackets® to cool before removing them from your amp. Handle Yellow Jackets® only by brown tube base.

Thank You!

Thank you for buying our Yellow Jackets® converter! It will provide you with years of service, assuming that you replace the tubes when they are worn, and will also give you a much greater variety of sounds from your amplifiers than you have ever experienced before.

www.yellowjacketstc.com

How to Install Yellow Jackets®:

1. With your amplifier cold and turned off, remove the 6L6, EL34, 7027, or 6V6 tube from its socket. (Use a towel to protect your hands if the tubes are hot).

- screw the ground wire under the tube socket mounting screw (to provide an adequate ground connection), and install a 6AQ5 tube into the Yellow Jackets® converter. Make sure that all pins are properly aligned and do not force anything. It should all go smoothly if the tube pins are properly aligned.
- is now running in Class A mode with a 6AQ5 output tube.

You do not have to adjust the bias of your amplifier as the Yellow Jackets® converters themselves create their own cathode bias circuit, ignoring the bias setting in your amp. This also means that when you put your old tubes back into the amplifier, your bias will be set just as you left it.

Please allow time for the Yellow Jackets® to cool before removing them from your amp. Handle Yellow Jackets® only by brown tube base.

Thank You!

Thank you for buying our Yellow Jackets® converter! It will provide you with years of service, assuming that you replace the tubes when they are worn, and will also give you a much greater variety of sounds from your amplifiers than you have ever experienced before.

How to Install Yellow Jackets®:

1. With your amplifier cold and turned off, remove the 6L6, EL34, 7027, or 6V6 tube from its socket. (Use a towel to protect your hands if the tubes are hot).

- 2. Place the Yellow Jackets® converter in the tube socket, screw the ground wire under the tube socket mounting screw (to provide an adequate ground connection), and install a 6AQ5 tube into the Yellow Jackets® converter. Make sure that all pins are properly aligned and do not force anything. It should all go smoothly if the tube pins are properly aligned.
- 3. Turn the amp on, let it warm up, and play. Your amp is now running in Class A mode with a 6AQ5 output tube.

You do not have to adjust the bias of your amplifier as the Yellow Jackets® converters themselves create their own cathode bias circuit, ignoring the bias setting in your amp. This also means that when you put your old tubes back into the amplifier, your bias will be set just as you left it.

Please allow time for the Yellow Jackets® to cool before removing them from your amp. Handle Yellow Jackets® only by brown tube base.

Thank You!

Thank you for buying our Yellow Jackets® converter! It will provide you with years of service, assuming that you replace the tubes when they are worn, and will also give you a much greater variety of sounds from your amplifiers than you have ever experienced before.

How to Install Yellow Jackets®:

1. With your amplifier cold and turned off, remove the 6L6, EL34, 7027, or 6V6 tube from its socket. (Use a towel to protect your hands if the tubes are hot).

- 2. Place the Yellow Jackets® converter in the tube socket, 2. Place the Yellow Jackets® converter in the tube socket, screw the ground wire under the tube socket mounting screw (to provide an adequate ground connection), and install a 6AQ5 tube into the Yellow Jackets® converter. Make sure that all pins are properly aligned and do not force anything. It should all go smoothly if the tube pins are properly aligned.
- is now running in Class A mode with a 6AQ5 output tube. is now running in Class A mode with a 6AQ5 output tube.

You do not have to adjust the bias of your amplifier You do not have to adjust the bias of your amplifier as the Yellow Jackets® converters themselves create their own cathode bias circuit, ignoring the bias setting old tubes back into the amplifier, your bias will be set just as you left it.

Please allow time for the Yellow Jackets® to cool before removing them from your amp. Handle Yellow Jackets® only by brown tube base.

Thank you for buying our Yellow Jackets® converter! It will provide you with years of service, assuming that you replace the tubes when they are worn, and will also give you a much greater variety of sounds from your amplifiers than you have ever experienced before.

How to Install Yellow Jackets®:

Thank You!

1. With your amplifier cold and turned off, remove the 6L6, EL34, 7027, or 6V6 tube from its socket. (Use a towel to protect your hands if the tubes are hot).

- screw the ground wire under the tube socket mounting screw (to provide an adequate ground connection), and install a 6AQ5 tube into the Yellow Jackets® converter. Make sure that all pins are properly aligned and do not force anything. It should all go smoothly if the tube pins are properly aligned.
- 3. Turn the amp on, let it warm up, and play. Your amp 3. Turn the amp on, let it warm up, and play. Your amp

as the Yellow Jackets® converters themselves create their own cathode bias circuit, ignoring the bias setting in your amp. This also means that when you put your in your amp. This also means that when you put your old tubes back into the amplifier, your bias will be set just as you left it.

> Please allow time for the Yellow Jackets® to cool before removing them from your amp. Handle Yellow Jackets® only by brown tube base.



If you have an amp with 4 output tubes, you have a
If you have an amp with 4 output tubes, you have a number of options:

a. Replace all 4 output tubes with Yellow Jackets®.

the amp, giving you about 10% power. In this case, install the Yellow Jackets® in the inner two sockets. (You do not need to adjust the impedance selector on your amplifier to compensate for using only two output tubes. You can keep it set to the impedance of your speaker cabinet with no danger of causing damage to the transformer.)

c. Leave two output tubes in the outside sockets and c. Leave two output tubes in the outside sockets and install two Yellow Jackets® in the inside two sockets. This will give you a combination of Class A Triode and Class AB Pentode operation, a very cool, responsive sound!

Other Thoughts Regarding Yellow Jackets®:

This NOS Yellow Jacket® is designed with an NOS 6AQ5 seven-pin miniature beam power tube, which is included with the converter. The 6AQ5 was used in many vintage practice guitar amps in the 1950s as well as many film projectors in the past. This tube is popular with DIY amp builders who often convert old film projectors into guitar amps. While electronically equivalent to the 6V6 with a slightly lower power rating, the 6AQ5 has its own unique vintage tone that sets it apart from its eight-pin big brother.

If you are not sure if this Yellow Jackets® converter will work in your amp, please feel free to contact us either by phone or by e-mail. We will be happy to advise you on your individual situation.

Amplifiers which vary the bias voltage to create a tremolo effect will not have any tremolo effect when using Yellow Jackets®. This includes the Fender® Brown Deluxe Amp (6G3), Princeton, Tremolux (5G9, 6G9), and Vibrolux (5F11, 6G11) to name a few.

If your amp uses 7591 output tubes, you need YJ7591 Yellow Jackets converters. The correct unit can be obtained from your local dealer or from us.

Thank you once again for buying our products. Without Thank you once again for buying our products. Without customers like you, we would have nothing to do all day.

- All the folks at CE Manufacturing, LLC

number of options:

a. Replace all 4 output tubes with Yellow Jackets®.

b. Remove all 4 tube and put only 2 Yellow Jackets® in b. Remove all 4 tube and put only 2 Yellow Jackets® in the amp, giving you about 10% power. In this case, install the Yellow Jackets® in the inner two sockets. (You do not need to adjust the impedance selector on your amplifier to compensate for using only two output tubes. You can keep it set to the impedance of your speaker cabinet with no danger of causing damage to the transformer.)

> install two Yellow Jackets® in the inside two sockets. This will give you a combination of Class A Triode and Class AB Pentode operation, a very cool, responsive sound!

Other Thoughts Regarding Yellow Jackets®:

This NOS Yellow Jacket® is designed with an NOS 6AQ5 seven-pin miniature beam power tube, which is included with the converter. The 6AQ5 was used in many vintage practice guitar amps in the 1950s as well as many film projectors in the past. This tube is popular with DIY amp builders who often convert old film projectors into guitar amps. While electronically equivalent to the 6V6 with a slightly lower power rating, the 6AQ5 has its own unique vintage tone that sets it apart from its eight-pin big brother.

If you are not sure if this Yellow Jackets® converter will work in your amp, please feel free to contact us either by phone or by e-mail. We will be happy to advise you on your individual situation

Amplifiers which vary the bias voltage to create a tremolo effect will not have any tremolo effect when using Yellow Jackets®. This includes the Fender® Brown Deluxe Amp (6G3), Princeton, Tremolux (5G9, 6G9), and Vibrolux (5F11, 6G11) to name a few.

If your amp uses 7591 output tubes, you need YJ7591 Yellow Jackets converters. The correct unit can be obtained from your local dealer or from us.

customers like you, we would have nothing to do all day.

- All the folks at CE Manufacturing, LLC

If you have an amp with 4 output tubes, you have a number of options:

a. Replace all 4 output tubes with Yellow Jackets®.

b. Remove all 4 tube and put only 2 Yellow Jackets® in the amp, giving you about 10% power. In this case, install the Yellow Jackets® in the inner two sockets. (You do not need to adjust the impedance selector on your amplifier to compensate for using only two output tubes. You can keep it set to the impedance of your speaker cabinet with no danger of causing damage to the transformer.)

install two Yellow Jackets® in the inside two sockets. This will give you a combination of Class A Triode and Class AB Pentode operation, a very cool, responsive sound!

Other Thoughts Regarding Yellow Jackets®:

This NOS Yellow Jacket® is designed with an NOS 6AQ5 seven-pin miniature beam power tube, which is included with the converter. The 6AQ5 was used in many vintage practice guitar amps in the 1950s as well as many film projectors in the past. This tube is popular with DIY amp builders who often convert old film projectors into guitar amps. While electronically equivalent to the 6V6 with a slightly lower power rating, the 6AQ5 has its own unique vintage tone that sets it apart from its eight-pin big brother.

If you are not sure if this Yellow Jackets® converter will work in your amp, please feel free to contact us either by phone or by e-mail. We will be happy to advise you on your individual situation.

Amplifiers which vary the bias voltage to create a tremolo effect will not have any tremolo effect when using Yellow Jackets®. This includes the Fender® Brown Deluxe Amp (6G3), Princeton, Tremolux (5G9, 6G9), and Vibrolux (5F11, 6G11) to name a few.

If your amp uses 7591 output tubes, you need YJ7591 Yellow Jackets converters. The correct unit can be obtained from your local dealer or from us.

Thank you once again for buying our products. Without customers like you, we would have nothing to do all day.

- All the folks at CE Manufacturing, LLC

If you have an amp with 4 output tubes, you have a If you have an amp with 4 output tubes, you have a number of options:

a. Replace all 4 output tubes with Yellow Jackets®.

b. Remove all 4 tube and put only 2 Yellow Jackets® in b. Remove all 4 tube and put only 2 Yellow Jackets® in the amp, giving you about 10% power. In this case, install the Yellow Jackets® in the inner two sockets. (You do not need to adjust the impedance selector on your amplifier to compensate for using only two output tubes. You can keep it set to the impedance of your speaker cabinet with no danger of causing damage to the transformer.)

c. Leave two output tubes in the outside sockets and c. Leave two output tubes in the outside sockets and install two Yellow Jackets® in the inside two sockets. This will give you a combination of Class A Triode and Class AB Pentode operation, a very cool, responsive sound!

Other Thoughts Regarding Yellow Jackets®:

This NOS Yellow Jacket® is designed with an NOS 6AQ5 seven-pin miniature beam power tube, which is included with the converter. The 6AQ5 was used in many vintage practice guitar amps in the 1950s as well as many film projectors in the past. This tube is popular with DIY amp builders who often convert old film projectors into guitar amps. While electronically equivalent to the 6V6 with a slightly lower power rating, the 6AQ5 has its own unique vintage tone that sets it apart from its eight-pin big brother.

If you are not sure if this Yellow Jackets® converter will work in your amp, please feel free to contact us either by phone or by e-mail. We will be happy to advise you on your individual situation.

Amplifiers which vary the bias voltage to create a tremolo effect will not have any tremolo effect when using Yellow Jackets®. This includes the Fender® Brown Deluxe Amp (6G3), Princeton, Tremolux (5G9, 6G9), and Vibrolux (5F11, 6G11) to name a few.

If your amp uses 7591 output tubes, you need YJ7591 Yellow Jackets converters. The correct unit can be obtained from your local dealer or from us.

Thank you once again for buying our products. Without Thank you once again for buying our products. Without customers like you, we would have nothing to do all day.

- All the folks at CE Manufacturing, LLC

number of options:

a. Replace all 4 output tubes with Yellow Jackets®.

the amp, giving you about 10% power. In this case, install the Yellow Jackets® in the inner two sockets. (You do not need to adjust the impedance selector on your amplifier to compensate for using only two output tubes. You can keep it set to the impedance of your speaker cabinet with no danger of causing damage to the transformer.)

install two Yellow Jackets® in the inside two sockets. This will give you a combination of Class A Triode and Class AB Pentode operation, a very cool, responsive sound!

Other Thoughts Regarding Yellow Jackets®:

This NOS Yellow Jacket® is designed with an NOS 6AQ5 seven-pin miniature beam power tube, which is included with the converter. The 6AQ5 was used in many vintage practice guitar amps in the 1950s as well as many film projectors in the past. This tube is popular with DIY amp builders who often convert old film projectors into guitar amps. While electronically equivalent to the 6V6 with a slightly lower power rating, the 6AQ5 has its own unique vintage tone that sets it apart from its eight-pin big brother.

If you are not sure if this Yellow Jackets® converter will work in your amp, please feel free to contact us either by phone or by e-mail. We will be happy to advise you on your individual situation.

Amplifiers which vary the bias voltage to create a tremolo effect will not have any tremolo effect when using Yellow Jackets®. This includes the Fender® Brown Deluxe Amp (6G3), Princeton, Tremolux (5G9, 6G9), and Vibrolux (5F11, 6G11) to name a few.

If your amp uses 7591 output tubes, you need YJ7591 Yellow Jackets converters. The correct unit can be obtained from your local dealer or from us.

customers like you, we would have nothing to do all day.

- All the folks at CE Manufacturing, LLC

www.yellowjacketstc.com www.yellowjacketstc.com www.yellowjacketstc.com www.yellowjacketstc.com

CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789 info@yellowjacketstc.com www.yellowjacketstc.com

CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789 info@yellowjacketstc.com www.yellowjacketstc.com

CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789 info@yellowjacketstc.com www.yellowjacketstc.com

CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789 info@yellowjacketstc.com www.yellowjacketstc.com

CE Manufacturing, LLC 6221 S. Maple Avenue Tempe, AZ 85283 Phone: 480.755.4712 Fax: 800.706.6789 info@yellowjacketstc.com www.yellowjacketstc.com