

IN HOUSE ASSEMBLY TEMPLATE


TOOLS REQUIRED


1/2" WRENCH

1/2" SOCKET AND TORQUE WRENCH - OPTIONAL **4MM ALLEN WRENCH**


ASSEMBLY COMPONENTS			
ITEMS INCLUDED	PART #	PART DESCRIPTION	QTY
TOP AND APRON ASSEMBLY	N/A	TOP ASSEMBLY (FACTORY ASSEMBLED)	1
LEGS	VARIES	LEG, (OAK OR MAPLE) 2.25X2.25X28.25	4
LEG HARDWARE	520001-4	LEG HARDWARE KIT,4 LEGS	1
LEG BOOT	100076	LEG BOOT,BLK RUBBER	4
STRETCHER	N/A	STRETCHER - SIZE VARIES	1
LEG BRACE	N/A	LEG BRACE - SIZE VARIES	2
CONFIRMATS - LEGS	227578	SCREW,7MMX90MM,CONN,ALLENHEAD, BLACK	8
CONFIRMATS - STRETCHER	228564	SCREW,7MMX50MM,CONN,ALLENHEAD, BLACK	4

A CCEAADLY COAADONIENITC










INSERT STRETCHER ONCE LEG BRACES ARE IN POSITION. ATTACH STRETCHER

WITH THE CONFIRMATS PROVIDED. GO BACK TO STEP 2 AND TIGHTEN UP THE

hanger bolt for each leg using a $\not\!$ wrench or $\not\!$ socket and torque wrench, to a minimum of 12ft Lbs but not to exceed 17ft Lbs .



TURN TABLE OVER SO TOP IS UP. SET YOUR TABLE IN PLACE AND ADJUST LEG LEVELERS TO LEVEL THE TABLE. SLIDE LEG BOOTS DOWN TO FLOOR.

