



NOT TO SCALE

Hardware is located in a separate box.

**POST AND ANCHOR INSTALLATION:**

1. When installing post, use bottom collar to ensure post height is about 31" above the court surface.
2. Posts should be spaced 22' apart (measured inside-to-inside).
3. **DIRECT GROUND INSTALLATION**  
Anchor each post in a block of concrete as shown in the diagram. Pour the concrete into a bell-shaped hole 24" in diameter at the top and 30" in diameter at the bottom. Make the hole at least 36" deep.
4. **GROUND SLEEVE INSTALLATION -Recommended**  
While pouring the concrete hold the ground sleeve in place, plugged end down. Use a plumb line to set the sleeve pointing straight up. Sleeve should be set flush with the surface. Let concrete dry. Carefully set the post in ground sleeves.

5. Adjust set screw to tighten tennis post cap.
6. Screw on the top and bottom eyebolts to each post.

During the off season, it is best to winterize your court by removing the tennis posts and use sleeve plugs (sold separately) to prevent moisture and dirt from falling in.

**CARE & MAINTENANCE**

## POP Tennis Net Installation \*Pickleball Nets are sold separately.

1. Stretch out the net across the court.
2. Attach the loop on the other end of the cable to the hook half way down the outside of the "dummy" post.
3. On take up post, attach one end of cable to the hook on the reel, turn clockwise a couple times to wrap around reel.
4. Turning the handle clockwise, crank up cable so center of net is approximately 38". DO NOT OVERWIND.
5. Insert dowels (provided) through the end side tapes.
6. To secure the net with provided lacing cord; You will receive (2) shorter white pieces of cord and (2) longer pieces of black cord. Take one piece of white lacing cord and tie a knotted loop approximately 2" at one end. Use this white cord to lace through the (2) grommets on the net headband, as well as the 1st top grommet on the side of the net; tie a knot and secure

- to top eyebolt. Next, use the black cord and start by tying the top of the black cord to the top eyebolt, and proceed in lacing the cord through the grommets and onto the lacing rods (if available) or around the post. Continue this along the entire side of the net. As you move down the post, keep tension on the lacing cord. Once the lacing cord has been installed through all the grommets, begin at the top and pull on the lacing cord until the net is flush against the net post from top to bottom. Once the net is flush against the net post, tie the lacing cord at the bottom of the net post to the eyebolt. Cut off any excess lacing cord. Repeat for other post.
8. Your installation is now complete. Your net should sit comfortable but somewhat taut between the net posts with a small gap between the net and posts.

