



**NEW** mounting brackets adjust up to 5" so they will align in thick portion of door frame. (Standards may have to be cut to fit shorter doors.)

**STEP 1: Figure 1**

Measure center (top) to center (bottom) on inside door frame rails.

**STEP 2:**

Transfer measurement from **STEP 1** to standards and tighten screws.



**STEP 3:**

Remove door from cabinet and lay face down on a towel to protect finished surface.

**STEP 4: Figure 2**

Mark center line of door (side to side)

**STEP 5: Figure 3**

Position one standard on back of door with slats pointed towards top of door.

**STEP 6: Figure 4**

Align standard parallel to edge of door using spacing according to Dimension "B".

**STEP 7:**

Fasten to door panel frame using screws furnished.

**CAUTION:** Determine thickness of door panel and make sure screws are not too long and do not come thru front of panel.

**STEP 8:**

Repeat **STEP 6** with other standard. Make sure bottom of both standards are level with each other so shelves hang level.

**STEP 9:**

Replace door to cabinet and hang spice shelves on standards.

## READ THIS FIRST!

**NOTE:**

The standards can be moved side to side if necessary to clear hardware or partition so shelves will clear opening as door swings open.

