



PLEASE NOTE:

- 1) FOR SAFE OPERATION AND CONTINUED HIGH PERFORMANCE FROM THIS EQUIPMENT, INSPECTION AND MAINTENANCE MUST BE PERFORMED BEFORE EACH USE
- 2) USE OF THIS EQUIPMENT OTHER THAN INTENDED, MAY BE HAZARDOUS.
- 3) ALTERATION OR MODIFICATION OF EQUIPMENT MAY BE HAZARDOUS. FOR REPAIR OR REPLACEMENT, PLEASE CALL YOUR DEALER

Jaypro Sports	MODEL NO.:
H-1	PRODUCT NAME:
976 Hartford Turnpike	HELMET STAKMASTER
Waterford, CT 06385 USA	
(800)243-0533	
(800)988-3363 Fax	
www.jaypro.com	
DRAWN BY: JAC	EFFECTIVE DATE: 1-5-04

JAYPRO SPORTS
HELMET STACKMASTER, H-1
LIST OF MATERIALS

<u>PIECE NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	H1B3	BOTTOM FRAME	1
2	H1B1	TOP BRACE	1
3	H1U1	UPRIGHT	4
4	EC0025	CAP	56
5	HN264	3/8" HEX NUT	4
6	RW2250	SWIVEL CASTER	4
7	HW337	3/8" WASHER	4

ASSEMBLY INSTRUCTIONS

1. APPLY SWIVEL CASTER (6) INTO WELD NUT ON BOTTOM FRAME (1) AND TIGHTEN FIRMLY. SECURE THE 3/8" HEX NUTS (5) ONTO THE STEM OF THE SWIVEL CASTER (6).
2. SLIP PLASTIC END CAPS (4) ONTO THE HELMET RODS AS SHOWN. FOR EASIER ASSEMBLY, SLIGHTLY MOISTEN THE INSIDE OF EACH END CAP.
3. PLACE THE UPRIGHTS OVER THE TUBING LOCATED ON THE BOTTOM FRAME. HELMET RODS SHOULD BE AT A 45 ANGLE TO THE CORNERS OF THE BASE FRAME (1), AND SLIP THE TOP BRACE (2) INTO THE UPRIGHTS. LEVEL UNIT BY ADJUSTING CASTERS.

IMPORTANT NOTE

THIS UNIT IS DESIGNED FOR THE STORAGE AND TRANSPORTATION OF FOOTBALL HELMETS ONLY. EXERCISE REASONABLE CAUTION WHEN TRANSPORTING THIS UNIT OVER THRESHOLDS, DOOR JAMS OR OTHER SIMILAR OBSTRUCTIONS.