

JAYPRO SPORTS

BOX LACROSSE GOAL WITH FLAT BACKSTAY, LG-44F LIST OF MATERIALS

<u>PIECE NO.</u>	PART NO.	DESCRIPTION	QTY.
1	N/A	FLAT BACKSTAY	4
2	N/A	RETAINING WASHER M10	8
3	N/A	FLAT WASHER M10	8
4	N/A	M10 ALLEN HEAD, PAN HEAD BOLT	8
5	N/A	MOUNTING PLATE	2
6	N/A	UPRIGHT	4
7	N/A	CROSSBAR	2
8	N/A	SOCKET HEAD SET SCREW M10 x 16	12

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED: 5 mm & 6 mm ALLEN WRENCH (PROVIDED)

- 1) POSITION BACKSTAYS (1) ON A LEVEL SURFACE AND JOIN REAR OF GOAL USING THE MOUNTING PLATE (5) AND FASTENERS AS SHOWN IN THE ILLUSTRATION. DO NOT TIGHTEN FASTENERS.
- 2) SLIP UPRIGHTS (6) ONTO THE HUB OF EACH BACKSTAY THEN PLACE THE CROSSBAR (7) INTO POSITION. THE NET TIE RAILS FACE TOWARD THE REAR OF THE GOAL.
- 3) SQUARE THE GOAL, CHECK FOR 48" INSIDE DIMENSION FOR THE GOAL FACE. THEN, FULLY TIGHTEN ALL HARDWARE.
- 4) CHECK HARDWARE BEFORE EACH USE TO ENSURE FASTENERS ARE FULLY TIGHTENED.