



INSTALLATION PROCEDURE:

- 1. Locate top net corners
- 2. Temporarily attach top net corners to top corners of face frame, using short length of lacing twine or zip ties.
- 3. Temporarily attach front bottom net corners to bottom corners of face frame, using short length of lacing twine or zip ties.
- 4. Lace net to frame starting from the middle of the crossbar and work your way out to corners and then down the posts.
- 5. Lace net bottom to groundstays.
- 6. Attach body-fit rope to rear vertex of goal.
- 7. Attach rope to top corners of frame, running the rope under the net.
- 8. Pull ropes to adjust net fit/tightness and then tie off to lock in fit.

INNOVATION, PERFORMANCE AND COMMITMENT SINCE 1953