

689 Mercedes Fuel Line Pliers

These pliers are designed for quick connect, slide and lock couplers found on European and domestic vehicle fuel lines.

- Applications include Audi, GM, Mercedes including M-Class, Toyota and VW models.
- Also can pull fuel and vacuum hoses on Mercedes models.



732 AC Belt Installation Tool

Used for the installation of AC Belts on BMW cars.

- Specifically crafted for BMW years 2006 - 2010 & 2012 - 2015.
- Designed for use on BMW V8 N62 vehicles.



195 Power Steering Pump Pulley Removal & Installer

This kit has nearly everything you need to remove and install power steering pump pulleys in Chrysler, Ford, and GM vehicles with Saginaw, Thompson, and Ford C111 and C2 power steering pumps.

Fits 1-1/8", 1-1/4", 1-5/16" and 1-3/8" pulley hub diameters, including the following:

- 1988–Newer GM cars equipped with Quad 4 engines
- 1991–94 GM 3.1L V6; 1991–Newer 3800 V6 engines
- 1992–Newer Ford Crown Victoria and Mercury Grand Marquis with 4.6 V8 engine
- 1994–Newer GM 3100 V6
- 1997–Newer Ford Truck with 4.2 & 4.6 V6, 5.4 V8, and 6.8 V10 engines
- 1999–Newer GM 3400 V6



751 GM Thermostat Wrench

The GM Thermostat Wrench is designed to work on GM 3.1 & 3.4 liter V6 engines. A common job on these motors is thermostat replacement and to do this you must remove the thermostat housing. In these applications the bottom housing bolt is almost inaccessible without removing other parts - until now.

Our GM thermostat wrench, with its unique shape and design, will allow users to remove and install the housings in a fraction of the time. The wrench is a 13 mm, 12 point with special bends specifically for GM V6 thermostat housings.

