# FUEL INJECTION ADAPTERS & REPLACEMENT PARTS

#### 33062

**HOSE 3/16" ID X 6 FEET** 



34021



1/4" I.D. X 6" **FUEL HOSE** 



35031

5/16" I.D. X 6"

**FUEL HOSE** 

36032

3/8" I.D. X 6" **FUEL HOSE** 



41303

3/16" HOSE

41310

**3/16 HOSE BARB X QC PLUG** 



# 41327

**OTC QUICK COUPLER BODY** 



41576

**BENT TUBE W/** 3/8" INVERTED **FLARE NUT** 



43110

5 PACK -O'RING



43141

5 PACK -

O'RING M14

60236

M16 x 1.50 **FEMALE BY** 3/8" TUBE END



60238

 $M14 \times 1.50$ **FEMALE BY** 3/8" TUBE **END** 



#### 60239

**J-BODY ADAPTER** 



# 60410

M8 x 1.00 **FEMALE BY** M12 x 1.50 MALE



### 60440

 $M10 \times 1.00$ **FEMALE BY** M12 x 1.50 MALE



### 60772

**OTC QUICK COUPLER PLUG** 



# 61333

**6MM ADAPTER EXTENSION FOR SCHRADER** 



# **KIA & HYUNDAI HOSE ASSEMBLY**

71301

STANDARD



# 71302

**SMALL PARTS** 



#### 71303

**ADER HOSE ASSEMBLY** 



### 71304

M6 x 1.00 (HONDA) HOSE **ASSEMBLY** 



# 71305



71306

### 71308

M14 x 1.50 **INVERTED FLARE MALE AND FEMALE CONNECTIONS** 



# FUEL INJECTION ADAPTERS & REPLACEMENT PARTS

#### 71313

**FORD EFI SPRING LOCK ADAPTER W/** QUICK COUPLER **PLUG** 



#### 71314

**FORD CFI SPRING LOCK** ADAPTER, **ADAPTER W/** 5/16" QUICK **SMALL** DISCONNECTS **SCHRADER** 



KIT

71315

ADAPTER. 5/16" QUICK **DISCONNECTS** W/ SMALL **SCHRADER** 



71328

#### 71316

**MANIFOLD** W/QUICK **COUPLER PLUG** 

71317



# 71318

**STANDARD SCHRADER** HOSE **ASSEMBLY** W/QUICK **COUPLER PLUG** 

#### 71319

**SMALL SCHRADER HOSE ASSEM** -BLY W/QUICK **COUPLER PLUG** 



#### 71321

**M16 O-RING ADAPTER** 



### 71327

**FUEL INJECTION 1/4" HOSE BARB W/QUICK COUPLER PLUG** 



#### 71329

HOSE **ASSEMBLY** (AUDI, VW, VOLVO)



71330

HOSE



#### 71403

**ADAPTER KIT** 



# 71404

**ADAPTER M8 x 1.00 MALE** BY M12 x 1.50 **MALE W/O-RING** 



# 71405

**ADAPTER** M10 x 1.00 MALE BY M12 x 1.50 **MALE W/O-RING** 



# 71406

**ADAPTER M8 x 1.00 MALE** BY M12 x 1.50 **MALE W/O-RING** (3" OVERALL)



# 71408

**CONNECTING HOSE AND VALVE ASSEMBLY FOR BOSCH CIS** 



KIT



**SMALL SCHR-**



**VOLVO** ADAPTER, **14MM LH JETRONIC** 

**M11 O-RING ADAPTER** 



#### 72305

**BENT TUBING** W/ 3/8" INVER-**TED FLARE NUT** BY M16x 1.50 NUT, 3/8" O-**RING FLARE** 



### **72306**

**ADAPTER** M<sub>16</sub> x 1.50 THREAD W/ 3/8" O-RING **FLARE BY 3/8" TUBE FITTING** 



### 72308

CONNECTING **HOSE FOR GM** TBI 3/8" INVER-**TED FLARE ENDS** W/QUICK **COUPLER PLUG** 



#### 72309

**ADAPTER** M14 x 1.50 **THREAD W/ 3/8" O-RING FLARE BY 3/8" TUBE FITTING** 



# 71409

**CIS & BANJO BOLD ADAPTER SET** 







# **FUEL INJECTION ADAPTERS & REPLACEMENT PARTS**

Part		J-26	J-113	J-443	J-446	J-447	J-448	J-457	J-469	J-480A	J-485A	J-550	476	489	J-443-2	J-443-3	TU-540-1	J-540-2
No.	Description	Ĕ	Ĕ	Ĕ	Ĕ	<u>Ĕ</u>	Ĕ	<u>Ĕ</u>	Ĕ	f	<u></u>	Ĕ	74	74	<u>Ĕ</u>	Ĕ	F	F
72315	Manifold with standard Schrader	•																
72316	3/8" male stem adapter GM/TBI	•																
72317	3/8" flare adapter GM/TBI	•																
72318	M16x1.50 GMTBI adapter	•																
72319	M16x1.50 female by 3/8" quick coupler plug	•																
72320	M16x1.50 long stem quick coupler GM/TBI	•																
72321	Cut hose, 3 pieces. Consists of: 34201,35031 and 36032			•						•		•						
72322	Consists of 60236, 72305 and 72306																	
74423	Repair parts kit											•						
74424	Gauge assembly											•						
74425	Hose assembly											•						
74426	M12x1.00 Honda pulse dampener adapter											•			•	•	•	
74431	Banjo bolt M6x1.00 with o-ring			•						•	•	•					•	
74432	Banjo bolt M8x1.00 with nylotron washer			•						•	•	•						
74433	Banjo bolt M10x1.00 with nylotron washer			•						•	•	•					•	
74434	Banjo bolt M12x1.25 with nylotron washer			•						•	•	•					•	
74435	Banjo bolt M12x1.50 with nylotron washer			•						•	•	•						
74437	Repair parts kit			•	•	•	•			•	•							•
74438	100 PSI gauge, hose and relief valve			•					•	•								
74440	100 PSI gauge and hose					•	•											
74442	60 PSI gauge and hose				•													
74444	Bosch CIS kit: 71408 and 71409																	
74445	Upgrade kit (except CIS/TBI): 71308, 71313, 71314, 71318, 71319 and 71327																	
74446	Relief valve and tubing assembly																	
74454	OTC-style conversion adapter, use Lang adapters with OTC canister																	
74455	Straight tubing, nut and clamp parts kit			•	•					•		•						•
74459	Quick coupler socket by male standard Schrader																	
74469	Conversion adapter OTC																	

# **FUEL INJECTION ADAPTERS & REPLACEMENT PARTS**

Part		J-26	J-113	J-443	J-446	J-447	J-448	TU-457	J-469	J-480A	J-485A	J-550	1476	1489	J-443-2	J-443-3	<b>FU-540-1</b>	U-540-2
No.	Description	F	F	<u>F</u>	<u>F</u>	<u> </u>	F	<u>F</u>	F	<u> </u>	上	<u>F</u>	74	74	<u>F</u>	F	F	F
74471	M14x1.50 banjo bolt (for CIS)											•			•	•		
74476	Road tester hose												•					
74484	5/16" quick disconnect hose assembly with quick coupler plug: Chrysler, Ford										•	•		•	•			
74485	3/8" quick disconnect hose assembly with quick coupler plug: GM										•	•		•	•			
74486	GSI conversion adapter, use GSI adapters with Lang gauges and canister																	
74487	Hose assembly: 74484 and 74485																	
74488	Hose assembly: 74492 and 74493																	
74492	5/16" quick disconnect hose assembly with standard Schrader test port																	
74493	3/8" quick disconnect hose assembly with standard Schrader test port																	
74494	GM tubing kit, consists of adapters: 41576 and 72305				•													•
74495	GM adapter kit, consists of adapters: 60236, 60238, 60239, 72306, 72309 and 74434				•													
74499	1/4" quick disconnect hose assembly with quick coupler plug																	
74571	Gauge and hose assembly							•										
74701	Gauge and hardware assembly										•							
74852	Standard Schrader right angle adapter with quick coupler plug											•		•				
74853	Small Schrader right angle adapter with quick coupler plug											•		•				
74854	Fuel injection update kit, consists of adapters: 74851, 74852 and 74853										•				•		•	



16 www.langtools.com