

22800 WHEEL STUD INSTALLER

Easily Installs New Wheel Studs.

Use with a ratchet or impact wrench to pull the new stud securely in place. Position the tool over the stud shaft. Tighten the lug nut against the tool to pull the stud in place. Works on most all automotive and light-duty truck wheel studs, foreign and domestic. NOTE: The bearing will wear with use and is not warranted.

22800 Wheel Stud Installer. Clam Shell. Shipping wt. 5 oz.

22820 Replacement Bearing & Dust Shield



U.S. Pat No. 7,421,769

28950 TRUCK WHEEL STUD INSTALLER

Installs Most Truck Wheel Studs in Seconds.

Use with an impact wrench or ratchet. The tool body is equipped with a thrust bearing to easily pull the new wheel stud into place. Fits truck wheel studs up to 22mm (7/8") in diameter. Use the lug nut to tighten against the tool body to pull the stud in position.

28950 Truck Wheel Stud Installer. Clam Shell. Shipping wt. 9 oz.

28970 Replacement Bearing and Dust Shield



U.S. Pat No. 7,421,769

13950 WHEEL STUD PILOT PIN SET

Easily Remove and Install Wheels on Many European Vehicles with Lug Bolts.

Three pairs of metric threaded wheel stud pilot pins allow you to hang the wheel without having to balance the wheel on the small lip of the hub. This helps prevent the wheel from falling and causing damage or injury. Simply insert threaded pins into hub bolt holes to hold the wheel in place while inserting or removing lugs. Set includes 12mm x 1.5, 14mm x 1.25 and 14mm x 1.5 threaded pins. Also available individually.

13950 Wheel Stud Pilot Pin Set. Skin-packed. Shipping wt. 1 lb. 11 oz.

13920 12mm x 1.5 Wheel Stud Pilot Pins

13930 14mm x 1.5 Wheel Stud Pilot Pins

13940 14mm x 1.25 Wheel Stud Pilot Pins



12mm x 1.5 fits:	BMW, VW, Mercedes, Porsche, and Mini Cooper.
14mm x 1.25 fits:	2009 and newer BMW 6 series, 7 series, X3, X5, X6 and Mini Cooper.
14mm x 1.5 fits:	VW, Mercedes, Porsche, BMW and Audi.

13970 12MM X 1.25 WHEEL STUD PILOT PINS

Easily Remove and Install Wheels on Fiat 500 and Dodge Dart Cars with Lug Bolts.

Wheel stud pilot pins allow you to hang the wheel without having to balance the wheel on the small lip of the hub. This helps prevent the wheel from falling and causing damage or injury. Simply insert threaded pins into hub bolt holes to hold the wheel in place while inserting or removing lugs. Works on 2013 and newer Dodge Dart and 2012 and newer Fiat 500 cars with 12mm x 1.25 metric lug bolts.

13970 12mmx1.25 Wheel Stud Pins. Skin-packed. Shipping wt. 8 oz.

