

Universal Defender™ Pads #GPB50M - 15" x 19", 50 pads/package



SonicBonded Mat Pads control spills and overspray to help keep floors dry and safe.

- **Fast-Acting for Quick Response:** A layer of MeltBlown polypropylene creates high surface area that enables SonicBonded Mat to quickly soak up liquids on contact.
- **High Absorbency Keeps It on the Job Longer:** A random assembly of large-diameter MeltBlown poly fibers creates a lofty layer. Mat absorbs high volumes of liquid fast. Great for catching overspray or soaking up spills.
- **Ultrasonic Bond Points Keep Mat Intact:** Ultrasonic bond points fuse layers of fibers together — Mat keeps its shape even when completely saturated. Top layer of lint-free SpunBond fabric provides extra strength. "Dimples" add fast-wicking power.
- **Perforations Save Money:** SpunBond top layer allows for better-defined perforations and cleaner, easier tear-offs. Pads are perfed vertically at 7.5".
- **Color-Coded:** Color-coding helps you visually identify the right sorbent for your needs. Grunge-hiding Gray signifies universal sorbency for oils, coolants, solvents and water.

GPB50M Specifications

Dimensions:	15" W x 19" L
Shipping Dimensions:	15" W x 19" L x 7" H
Sold as:	50 pads per package
Color:	Gray
Composition:	Polypropylene
Absorbency:	Up to 12.35 gal. per package
Absorbency per:	Up to 31.62 oz. per pad
Weight:	5.2 lbs.
# per Pallet:	48
Basis Weight:	MediumWeight
Incinerable:	Yes
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	38.1cm W x 48.3cm L
Shipping Dimensions:	38.1cm W x 48.3cm L x 17.8cm H
Absorbency:	Up to 46.7 L per package
Absorbency per:	Up to 935 mL per pad
Weight:	2.4 kg

GPB50M Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com