

Rig Mat Roll #RIG160H - 58" x 160', 1 roll/package



Save your site costly cleanups by stopping mess before it starts!

- **Absorbs Oily Liquids — Repels Water:** MeltBlown polypropylene fibers are left in their natural hydrophobic state. These hydrophobic fibers repel water while only absorbing oils and other hydrocarbons. Ideal for outdoor use — Mat provides quick, efficient cleanup to help protect the environment from contamination.
- **Our Rig Mat is Durable:** A tough top layer of Spunbond makes the Rig Mat strong to stand up to foot and vehicle traffic. It's ideal for service rigs, sucker rod maintenance, wellhead maintenance, cleaner drilling and clean compressor houses.
- **Multi-Perforations Save You Money:** Roll is perfed every 4'. Tear off only what you need — save money!
- **Color-Coded:** Color-coding helps you visually identify the right sorbent for your needs. Blue designates Oil-Only sorbency and fits into many professional surroundings.

RIG160H Specifications

Dimensions:	58" W x 160' L
Shipping Dimensions:	20" W x 58" L x 20" H
Sold as:	1 roll per package
Color:	Blue
Composition:	Polypropylene
Absorbency:	Up to 176.2 gal. per package
Weight:	62.9 lbs.
# per Pallet:	6
Basis Weight:	HeavyWeight
Incinerable:	No
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	147.3cm W x 49m L
Shipping Dimensions:	50.8cm W x 147.3cm L x 50.8cm H
Absorbency:	Up to 666.9 L per package
Weight:	28.5 kg

RIG160H Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com