

Oil-Only Contractor Grade Pads #WP-H - 15" x 18", 100 pads/package



If your priority is economy and short-term use for oil spills, Contractor Grade absorbents are the perfect choice. These oil-only pads are versatile enough to use for any outdoor spill.

- Highly absorbent MeltBlown polypropylene mat repels water and soaks up only oil and oil-based fluids
- Perfect for light-duty industrial, maintenance and general applications
- HighLoft construction is sturdy and soft
- Quickly absorbs leaks, spills and overspray to keep floors dry
- Pads are great for general cleanup applications

WP-H Specifications

| | |
|-----------------------------|---------------------------|
| Dimensions: | 15" W x 18" L |
| Shipping Dimensions: | 15" W x 18" L x 12" H |
| Sold as: | 100 pads per package |
| Color: | White |
| Composition: | Polypropylene |
| Absorbency: | Up to 22 gal. per package |
| Absorbency per: | Up to 28.2 oz. per pad |
| Weight: | 9 lbs. |
| # per Pallet: | 42 |
| Incinerable: | Yes |
| Ship Class: | 175 |

Metric Equivalent Specifications

| | |
|-----------------------------|--------------------------------|
| Dimensions: | 38.1cm W x 45.7cm L |
| Shipping Dimensions: | 38.1cm W x 45.7cm L x 30.5cm H |
| Absorbency: | Up to 83.3 L per package |
| Absorbency per: | Up to 833.9 mL per pad |
| Weight: | 4.1 kg |

WP-H Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com