

Materials



Step #1: Install WPS-7 and WPS-158P



Prep and install the 1-5/8" cable to install the JMA 1-5/8" DM connector connector. Refer to the 1-5/8" connector installation instructions.




Slide the dedicated 1-5/8" port seal onto the port base by stretching seal over the threads.



Push seal back to expose port threads.

Compatible Port Dimensions




1 SURFACE SHOULD BE FREE OF FLATS, THREADS, OR RAISED LETTERING WHOSE CHARACTERS ARE TALLER THAN 1/8".

2 MINIMUM DISTANCE BETWEEN END OF THREAD AND ANY OBSTRUCTION

Step #2: Connect and Torque Interface



Connect the JMA 1-5/8" DM connector to the antenna port or device and hand tighten.



Torque the connector to 18 ft. lbs. using the TQ-114-F18 torque wrench.

Step #3: Install JMA WPS to Seal Interface



Place the 1-5/8" adaptors over coupling nut. Adaptors should cover nut.



Pull the dedicated 1-5/8" port seal over the 1-5/8" adaptors.



Slide WPS-7 over the JMA 1-5/8" DM connector, making sure to overlap the dedicated 1-5/8" port seal.

Materials



Step #1: Install WPS-7 and WPS-158P



Prep and install the 1-5/8" cable to install the JMA 1-5/8" DF connector. Refer to the 1-5/8" connector installation instructions. Slide connector port seal (included with connector) onto JMA 1-5/8" DF connector just behind threads.



Slide the dedicated 1-5/8" port seal onto the port by stretching seal over the coupling nut.




Push seal back to expose port.

Step #2: Connect and Torque Interface




Connect the JMA 1-5/8" DF connector to the antenna port or device and hand tighten.



Torque the connector to 18 ft. lbs. using the TQ-114-F18 torque wrench and adjustable wrench.

Compatible Port Dimensions



1 SURFACE SHOULD BE FREE OF FLATS, THREADS, OR RAISED LETTERING WHOSE CHARACTERS ARE TALLER THAN 1/8".

2 MINIMUM DISTANCE BETWEEN END OF THREAD AND ANY OBSTRUCTION

Step #3: Install JMA WPS to Seal Interface



Place the 1-5/8" adaptors over coupling nut. Adaptors should cover nut.



Pull the dedicated 1-5/8" port seal over the 1-5/8" adaptors.



Slide WPS-7 over the JMA 1-5/8" DF connector, making sure to overlap the dedicated 1-5/8" port seal.