



Installation Instructions to Attach the JD Command Arm Bracket to a KM 1000, 1003, or 1300 Uni Pro Seat

1. Remove the right arm rest. Do not discard the mounting bolts and nuts.
2. Remove the seat belt from the right side.
3. Remove the seat cushion by pulling up on the front of it.
4. Place the control arm bracket in place so that the arm rest bolts run through the rear two holes. Hand tighten the nuts
5. Install the 5/16" bolts through the two seat pan holes with the spacers on the outside.
6. Re-install the seat belt on the right side so the bolt runs through the rear most slotted hole.
7. Attach the control arm using the metric bolts provided.
8. Adjust the control arm to desired height and fore-aft position and tighten all the bolts and nuts.
9. Re-install the seat cushion.