



1. Remove the old seat & suspension.
2. Use of original OEM seatbelt is required so removal of KM136 seatbelt is optional at this time.
3. Install the new seat & suspension down to the skid steer with the four 5/16"-18 x 1" button head socket cap screws and flange nuts.
4. Splice the 86419 harness provided to the skid steer wiring as described below.
  - Red - (Skidsteer) Orange -*this originally was for seat heat. \*Disregard on mechanical seat.*
  - Black - (Skidsteer) Black *\*Disregard on mechanical seat.*
  - Yellow - (Skidsteer) Red - *Operator presence switch +*
  - White - (Skidsteer) Yellow/Brown - *Operator presence switch -*
  - *Disregard the blue & green wires on harness.*
5. Connect 86419 harness to seat.