



5/16"-18x3/4" HEX HEAD BOLTS



5/16" LOCK WASHERS

Installation instructions for KM125 seat onto a Kubota B2650

1. Remove hinge pin and old seat.
2. Install KM bracket kit on KM125 seat as shown below using 5/16"-18x3/4" and 5/16" lock washers. NOTE: Use hardware provided to ensure use of proper threads.
3. Install new seat using seat hinge pin and cotter pin from old seat.

NOTE: Bottom of seat shown for clarity.

