

Installation Guide

Case Mini CX--B Mini Excavator KM 171 Kit (PN: 6962)

1. Remove original seat from the OEM plate. NOTE: You will have to remove the slide rails to get the original seat off.
2. Mount the two PED 6146 brackets to the bottom of the new seat using four 5/16" x 5/8" hex bolts.
3. Mount the seat and PED assembly to the OEM plate using four 5/16" x 3/4" hex bolts and flange nuts. Re-attach the slide rails and re-install in the cab.

