

1. Insert a 1/4" x 1/2" bolt through the backrest bracket and the seat bracket and fasten with a 1/4" locknut.

### Note!

**All bolts should be left loose until assembling is complete.**

2. Insert a 5/16" x 1/2" bolt with flat washer through the backrest bracket and fasten to the threaded hole in the seat bracket. Install the seat cushion with two 5/16" x 5/8" cap screws and lock washers. Install the backrest cushion by using a pair of the top two set of holes on the backrest bracket and two 5/16" x 5/8" cap screws and lock washers.
3. Insert two 5/16" x 1/2" bolts with flat washers through the armrest bracket. Fasten the bolts to the threaded holes on the backrest bracket.
4. Insert a 5/16" x 5/8" bolt with flat washer through the armrest bracket and the backrest bracket. This bolt is fastened to the threaded hole in the seat back.
5. Assemble the right hand brackets in the same order the left hand brackets were assembled.
6. Tighten all bolts securely.

