

1. Remove the old step from the tractor. Keep the hardware used to mount the step.
2. Attach the upper step section using the original hardware. Hand tighten only.
3. Attach one of the lower step sections and the handrail using the 3/8" x 3/4" and 3/8" x 1" bolts and 3/8" flange nuts provided. The 1" long bolts go on the side the handrail mounts to.
4. Slide the other lower step section along the outside of the step section installed in step 3. Locate at desired height and clamp in place.
5. Using the clamped step as a template, mark the location of the top two holes on each side. Remove the clamped step and drill the four holes with a 1/2" drill bit.
6. Attach the last lower step section to the assembly using four 3/8" x 3/4" bolts and flange nuts.
7. Rotate the step to the desired position and tighten the mounting bolts.

