

Instruction Guide

JD 8000 Series Drawbar Reinforcement - (PN: 1451)

**Fits 8000 and 8020 wheel tractors with 2" x 3" drawbars.
Will not fit 8520 wheel tractors.**

1. Remove the **PTO shield** as shown below.
2. Install the **side plates** using the four provided 20mm x 90mm bolts.
3. Bolt the **support bracket** to the **side plates** using four 5/8" x 2" bolts, lock washers and nuts. The 1/4" **spacer plate** goes between the **support bracket** and the **drawbar**.
4. Re-install the **PTO shield**.

Note!

When installing on an Early 8000 Series, use the 3/4" spacer blocks between the drawbar and the hammer strap, as shown. Fasten using the original bolts.

