

# Installation Guide

Nite-Gard™ CIH Magnum  
(PN: 3258)

1. Remove the old Warning Lights and Mounts. Keep the bolts, as they will be used to mount the new Warning Lights.
2. Mount the new Warning Light Brackets to the tractor using the original bolts and holes. The view shown is of the right hand side.
3. Mount the warning light arm to the horizontal mount bracket using the 3/8" x 1" bolts and flange nuts.
4. Locate the flasher circuit on the tractor.
5. Connect one wire to the flasher circuit and ground the other wire. Be sure to trim the wire on the warning light arm and discard any excess wire.
6. Loosen the knob and extend the light extension to desired position.
7. Re-tighten the knob. Do not over tighten.

