
FLEXA-TOUCH

INSTRUCTIONS

Attach unit to back of drawer with screws provided Slide drawer into place. Then, with unit in closed position, measure any misalignment in or out. Remove drawer to adjust knob.



Adjustment 7/8" (2 1/8" Min., 3" Max.)