

## **COP QUICK PROBE VS**

76562



Simply press the 7" long antenna probe against the ignition coil and use the thumb-wheel to adjust the sensitivity until the LEDs begin flashing.

Each time the unit detects a spark firing it will flash the bright LED strobe indicating sufficient kV and flash the green LED indicating sufficient Arc Duration. This allows the technician to determine if the coil is firing the spark plug consistently, intermittently misfiring or not firing at all.



## **Kit Contents**

- Super bright KV & ARC indicator LEDs
- 7" Signal receiver probe
- · Battery operated
- · Sensitivity thumb-wheel
- User guide



MORE PRODUCT INFORMATION

Toll Free 800-342-5080

**HICKOK WAEKON** 



