## **OXYGEN SENSOR TOOLS**





## 14 MM OXYGEN SENSOR WRENCH TOOL

This tool is a must for removing and installing H-D's new 4 wire heated Oxygen Sensors. The new fragile O2 sensor must be torqued to 14 ft-lbs, lending to the design of this tool to be used with a 3/8" drive torque wrench. For more details see No. 784-IS Instructions.

No.784 - Use on 2010-present FLH, Touring Models



This tool is used to remove or install the oxygen sensor on all closed loop fuel injected H-D $^\circ$  models. Socket has a 3/8" drive receiver or can be used with a 7/8" wrench. Socket will withstand up to 125 ft/lbs of torque.

No.**969** - Use on 2006-present XL, 2006-2011 VRSC, FXD, and FXST also 2006-2009 FLH and trike.