## WHEELTOOLS

#### LATE SEALED WHEEL BEARING REMOVER AND INSTALLER KIT



Use to remove and install "new style" sealed wheel bearings without damaging the wheel. Includes new remover and installer for 25mm bearing, with or without ABS. Also included is a 30 pack of "surface Temperature Indicating Strips." These are used to assist in removing a stubborn bearing when applying heat to a hub surface. For more details see No.1042-IS instructions.

No.939 - Use on all 2000-present Twin Cam<sup>®</sup> models, and all 2000 -present Sportster® models, Street 500 and 750 and V-Rod°s 2002-present.

## 25MM WHEEL BEARING REMOVER AND INSTALLER TOOL



This tool is used to remove and install the new front 25mm H-D° bearing, including ABS or non ABS wheel bearings on most of the 2007 to present with 25mm bearing models. Note: This tool must be used

with the earlier JIMS° wheel bearing installer / remover Tool No.1042 above. For more details see No.1042-IS instructions.

No.**958** -Use on all 2007-present wheels using 25mm wheel bearing, ABS or non-ABS.

| PARTS AVAILABLE SEPARATELY |      |                   |          |  |  |
|----------------------------|------|-------------------|----------|--|--|
| NO.                        | QTY. | DESCRIPTION       | PART NO. |  |  |
| 1                          | 1    | REMOVER           | 1042-8   |  |  |
| 2                          | 1    | INSTALLER         | 1042-9   |  |  |
| 3                          | 1    | INSTRUCTION SHEET | 1042-IS  |  |  |

# PARTS AVAILABLE SEPARATELY DESCRIPTION

| NU. | QII. | DESCRIPTION                     | PART NO. |
|-----|------|---------------------------------|----------|
| _1  | 1    | WHEEL BEARING PULLER (1.00" ID) | 1042-1   |
| 2   | 1    | WHEEL BEARING PULLER (.750" ID) | 1042-2   |
| _ 3 | 1    | MAIN BODY, PULLER               | 1042-3   |
| 4   | 1    | BEARING INSTALLER, LARGE        | 1042-4   |
| 5   | 1    | BEARING INSTALLER, SMALL        | 1042-5   |
| 6   | 1    | INSTALLER BACKING PLATE         | 1042-6   |
| 7   | 1    | EXPANDER DOWEL                  | 1042-7   |
| 8   | 1    | BEARING                         | 2010     |
| 9   | 1    | BOLT, 1/2-13 X 12"              | 2138     |
| 10  | 1    | BRASS WASHER                    | 1099     |
| 11  | 1    | FLAT WASHER. 1/2 SAE            | 2038     |
| 12  | 1    | NUT, 1/2-13                     | 2136     |
| 13  | 1    | NUT, 3/4-16                     | 1098     |
| 14  | 1    | NUT, 7/16-14                    | 7515     |
| 15  | 1    | WASHER, 7/16 SAE                | 2037     |
| 16  | 1    | REMOVER, 25MM                   | 1042-8   |
| 17  | 1    | INSTALLER, 25MM                 | 1042-9   |
| _18 | 1    | TEMPERATURE STRIPS (30)         | 899      |
| 19  | 1    | INSTRUCTION SHEET               | 1042-IS  |
|     |      |                                 |          |


SEE ON

You Tube

### AXLE INSTALLATION GUIDE NEW

Installation of motorcycle axles has always been problematic. Trying to align the wheel with other components such as swing arms, caliper brackets, wheel hubs and spacers can be frustrating - especially when trying to do the job alone. To help eliminate these problems, JIMS now offers an axle installation guide tool. This tool is exclusive to JIMS and was designed by our talented engineering partner,

No. 5820 - Use on all 2008 - present hollow 1" / 25mm standard axles.





212

Hiro Koiso.