

Rev A 8-08

# **INSTRUCTION SHEET FOR TOOL #1236**



#### PISTON RING COMPRESSOR SET USE ON ALL MODELS WITH PISTON SIZES -2 7/8" - 4 3/16"

- 1. Refer to H-D<sup>®</sup> or Cylmer Service Manual for specifications.
- Select the proper size band for the piston. Ranges are from 2 7/8"-4 3/16". Place lubed band around piston covering rings.
- 3. Hook pliers into band and compress. With the band tightly around piston, support the piston with one hand while sliding the cylinder on with the other. Remove piston ring compressor band. Push cylinder down to base.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS AND TOOL. SEE JIMS® CATA-LOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

*"Doing It Right... The JIMS" Way!"* 555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422

No.1236-IS



Rev A 8-08

## **INSTRUCTION SHEET FOR TOOL #1236**



### PISTON RING COMPRESSOR SET USE ON ALL MODELS WITH PISTON SIZES -2 7/8" - 4 3/16"

- 1. Refer to H-D<sup>®</sup> or Cylmer Service Manual for specifications.
- Select the proper size band for the piston. Ranges are from 2 7/8"-4 3/16". Place lubed band around piston covering rings.
- 3. Hook pliers into band and compress. With the band tightly around piston, support the piston with one hand while sliding the cylinder on with the other. Remove piston ring compressor band. Push cylinder down to base.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS AND TOOL. SEE JIMS® CATA-LOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

### "Doing It Right... The JIMS" Way!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-7422