

INSTRUCTION SHEET FOR No. 989

MAINSHAFT PULLEY NUT SOCKET

USE ON 2006 TO PRESENT DYNA AND 2007 TO PRESENT

FL AND FXST 6-SPEED CRUISE DRIVE TRANSMISSIONS

Refer to H-D® Service Manual for specifications.



This tool will easily remove and install the right hand threaded nut that holds the trans pulley on. The inner collar No. 1 is designed to be threaded onto the left-hand thread of the main shaft. With the inner collar in place, this will stop the tool from slipping when torquing the nut. See H-D® Service Manual for torque specs. Apply lube to threads of tool.

PARTS AVAILABLE SEPARATELY					
No.	Qty.	Description	Part No.		
1	1	INNER COLLAR	94660-37A-2		
2	1	SOCKET	989-2		

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! SEE JIMS® CATALOG FOR HUNDREDS OF TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

555 DAWSON DRIVE, CAMARILLO, CA 93012 PHONE 805-482-6913 • FAX 805-482-9224

VISIT US ON THE WEB AT WWW.JIMSUSA.COM

No.989-IS



REV C 4-15

INSTRUCTION SHEET FOR No. 989

MAINSHAFT PULLEY NUT SOCKET

USE ON 2006 TO PRESENT DYNA AND 2007 TO PRESENT

FL AND FXST 6-SPEED CRUISE DRIVE TRANSMISSIONS



This tool will easily remove and install the right hand threaded nut that holds the trans pulley on. The inner collar No. 1 is designed to be threaded onto the left-hand thread of the main shaft. With the inner collar in place, this will stop the tool from slipping when torquing the nut. See H-D® Service Manual for torque specs. Apply lube to threads of tool.

Refer to H-D[®] Service Manual for specifications.

PARTS AVAILABLE SEPARATELY				
No.	. Qty.	Description	Part No.	
1	1	INNER COLLAR	94660-37A-2	
2	1	SOCKET	989-2	

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! SEE JIMS® CATALOG FOR HUNDREDS OF TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.