

## INSTRUCTION SHEET FOR TOOL NO. 2232

STEERING HEAD BEARING RACE REMOVAL / INSTALLATION TOOL
USE TO INSTALL AND REMOVE BEARING RACES IN STEERING HEAD.
USE ON BIG TWIN 1949-PRESENT (EXCEPT 2014 TO PRESENT TOURING MODELS)
USE ON SPORTSTER 1978-PRESENT
USE ON V-ROD 2002-PRESENT



1. Refer to H-D<sup>®</sup> Service Manual for specifications. Use with JIMS<sup>®</sup> tool handle No. **33416-80** and driver spacer No. **2388**. Use a press fit lube.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE THE PARTS!

SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.

THE LAST TOOLS YOU WILL EVER NEED TO BUY.

## "FROM THE TRACK... TO THE STREET!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224

VISIT US ON THE WEB AT WWW.JIMSUSA.COM

No.2232-IS



REV B 12-15

## INSTRUCTION SHEET FOR TOOL NO. 2232

STEERING HEAD BEARING RACE REMOVAL / INSTALLATION TOOL
USE TO INSTALL AND REMOVE BEARING RACES IN STEERING HEAD.
USE ON BIG TWIN 1949-PRESENT (EXCEPT 2014 TO PRESENT TOURING MODELS)
USE ON SPORTSTER 1978-PRESENT
USE ON V-ROD 2002-PRESENT



1. Refer to H-D<sup>®</sup> Service Manual for specifications. Use with JIMS<sup>®</sup> tool handle No. **33416-80** and driver spacer No. **2388**. Use a press fit lube.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE THE PARTS!

SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.

THE LAST TOOLS YOU WILL EVER NEED TO BUY.

## "FROM THE TRACK... TO THE STREET!"