

SPINDLE NUT SOCKETS

2467
4-LUG 4WD SPINDLE NUT SOCKET 1/2 TO 3/4 - TON DANA 44



Remove and install 4-slot axle lock nuts on Ford Ranger, Bronco II, Explorer, F-Series, and full-size Bronco; GM 1/2-ton trucks and full-size Blazer/Jimmy; International 1/2-ton trucks; Dodge 1/2-ton trucks and Dodge with Dana 44

2770
6-LUG 4WD SPINDLE NUT SOCKET 3/4 TO 1 - TON DANA 44



Remove and install 4-slot front axle lock nuts on Ford F-Series 4WD trucks; Ranger, Bronco, GM 4WD 3/4- and 1-ton trucks; Dodge trucks with Dana 44

3195
4-LUG WITH EXTENSION 1/2 - TON DANA 80



For high-shear rotating nuts on F250-350 with Dana 80 rear axle 10-1/4" ring gear; E350 with Dana 80 rear axle and 10-1/4" ring gear; F super-duty with Dana 80 rear axle and 10-1/4" ring gear

3246
4WD SPINDLE NUT WRENCH



For use on GM 3/4- and 1-ton trucks; Ford F-Series 1/2-ton trucks with Dana 28, F250 and F350 4WD trucks

3910
4WD SPINDLE PULLER



Removes front spindle to access needle bearing when lubricating and aligning front wheels. 5/8"-18 fine thread permits use with slide hammer. Fits spindle thread sizes 2"-16, 1-5/8"-16, and M38 x 1.50 Applications: Full-size GM, Ford, Jeep and International pickups with Dana front axles, plus Ranger and Bronco II

3911
TOYOTA LOCK NUT TOOL



Servises high-torque lock nuts on Toyota 4WD vehicles having free-wheel (lock-out) hubs; Tacoma; T100 and 4-Runner

3937
4-LUG 4WD SPINDLE NUT SOCKET 1/2 - TON DANA 50



Remove and install 4-slot front axle nuts on Ford F250-350, Bronco with Dana Axle, or Dana 50IFS or model 60 monobeam axle outer adjusting nut; GM Heavy-duty 3/4- and 1-ton trucks



3246: 4WD Spindle Nut Wrench

AIR CHUCKS

- These air chucks are combined with our E-Z Grip handles to provide a comfort grip when using the air chuck
- Durable, heavy duty handle stands up to tough shop abuse
- 1/4" NPT pipe threaded end will accept an air line quick-disconnect fitting

780
E-Z GRIP DUAL HEAD AIR CHUCK



- Designed for use on trucks, dual rear wheels, semis, and hard-to-reach wheels

782
E-Z GRIP DUAL HEAD STRAIGHT AIR CHUCK TOOL



- Straight On Dual Head Tool permits access to hard to reach inner tandem wheels and includes the new tilt-lock feature which locks onto the valve

785
STANDARD AND LARGE BORE AIR CHUCK



- For inflating tires on large trucks and earth moving equipment with large bore valves

915
E-Z GRIP AIR CHUCK TOOL - PASSENGER VEHICLES



- Sealed ball air chuck is extended 1" from handle to allow access to tight areas

BATTERY CARRIERS

B-600
HEAVY DUTY BATTERY CARRIER



- For use on all batteries with horizontal ridges; Non-slip, acid resistant, riveted rubber grip pads secure a firm hold on any battery up to 7-1/2" wide
- Zinc-plated steel construction

B-610
BATTERY CARRIER - STRAP STYLE



- Accommodates battery size from 3-1/2" to 7-3/4"
- Jaws made from zinc-plated carbon steel
- Reinforced conveyor strapping handle

BATTERY TERMINAL

B-10A
5/16" RATCHETING SIDE TERMINAL BATTERY WRENCH



6525
5/16" EXTRA LONG RATCHETING SIDE TERMINAL BATTERY WRENCH



6571
5/16" X 10MM EXTRA LONG BATTERY TERMINAL WRENCH



6572
10MM BATTERY TERMINAL WRENCH



Part No.	Removes/installs 5/16" battery terminals	Removes/installs 10mm battery terminals and hold-down fasteners	Insulated handle to prevent electric shock	Reversible ratcheting box wrench allows for quick and effective bolt removal	Extra length (9-3/4") allows for easy access to recessed terminals
B-10A	•		•	•	
6525	•		•	•	•
6571	•	•	•	•	•
6572		•	•	•	

41701
BATTERY SERVICE KIT



- Terminal puller
- Nut pliers
- Terminal brush
- Terminal spreader and cleaner
- 5/16" x 10mm extra long terminal wrench