



KEY CHAIN ALARM

Protect yourself with a
LED Flashlight & 130-dB Alarm

With the *Streetwise Key Chain Alarm*, security is now as close as your keys.

A person is most likely to be attacked at night while walking to or from their home or car. This compact alarm conveniently attaches to your keys so you can be ready in a moment's notice to sound the 130dB alarm to scare off an attacker and summon help.

For added safety and convenience, the Key Chain Alarm has a built in LED flashlight.

IMPORTANT: Before this alarm will work the plastic tab must first be removed from the back. Pull out and discard the plastic tab.

Operation:

ALARM: To activate the alarm, simply press the RED button on the side of the unit. A partial press sounds the alarm until the button is released. A full press will sound the alarm until the button is pressed again.

FLASHLIGHT: To activate the flashlight, press the WHITE button located on the front of the unit. The light will turn off when the button is released.

BATTERY: A 12v alkaline battery (#23A) is included with this device. When the light or alarm is noticeably weaker, the battery will need to be replaced. Use a small screw driver to remove the cover on the back of the unit and replace the battery following the polarity diagram.

Streetwise Security Products extends a **one year warranty** to this product for defects in materials or workmanship. Contact an Authorized Dealer for more information.

