

— Instruction Manual —

TB50-B

Tetherball Assembly



Customer Service
(800) 247-7668

PARTS LIST					
Item	Qty	Description	Item	Qty	Description
A	1	Tetherball/Rope Assembly	C	1	1/4" Quick Link
B	1	30" Chain	D	1	Snap Link with Eyelet

- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- ◆ Read all instructions before proceeding.

1. Attach *1/4" Quick Link (C)* to one end of *30" Chain (B)*.
2. Attach *Snap Link with Eyelet (D)* to other end of the *30" Chain (B)*.
3. Attach *1/4" Quick Link (C)* to the eyebolt at the top of the tetherball pole.
4. Tie the rope that is attached to the tetherball to the eyelet in the *Snap Link with Eyelet (D)* so that the ball is at the desired height for play.
5. Remove the excess rope and singe end of rope with a lighter to eliminate fraying.

