

USER'S MANUAL
Kids Game Desk Chair Set
BB5252PI/BB5252WH/BB5252BL

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

- ⊙ Please read all instructions carefully.
- ⊙ Retain instructions for future reference.
- ⊙ Separate and count all parts and hardware.
- ⊙ Read through each step carefully and follow the proper order.
- ⊙ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⊙ Always place the product on a flat, steady and stable surface.
- ⊙ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Product Introduction


1.Product Information

Model: 8016 Product name: Kids Game Desk Chair Set Applicable Age: 1-3 years old
Product specification: 1 x Desk, 2 x Chair Main material: HDPE


2.Product Feature:

- (1)With stable structure and great durability, enviromental PE material will not be out of shape because it is not affected by the climate and temperature difference.
- (2)With humanized design, the desk edge is non-slipping, resisting to dirt and easy to clean.
- (3)Being safe, compact, easy to transport and disassemble, it is applicable for home, kindergarden, nursery, children's palace, etc.


Product Accessories




Deskboard x 1



Desk side panel x 2




Desk transom board x 1




Chair seat board x 2

Product Accessories




Chair side panel x 4



Chair backrest x 2



Nut x 10




Plastic tightening strip x 1

Before assembly,
check whether the accessories are complete.

Product Assembly - Desk

1

Insert the transom board uprightly into the rung of the middle of side panel. Install the nut at the position shown in the diagram (the nut can be tightened with a coin) to strengthen the connection.




4

Product Assembly - Desk


2

Connect the other end of the transom board to the other side panel in the same way.



3


Point the grooved side of the deskboard downward and aim it at the corresponding position of the side panel. Press hard and install the deskboard (when hearing the sound of "click", it means it has been firmly installed).




5

Product Assembly - Chair


- 1** According to the order of the chair side panel, chair backrest, chair side panel, insert them to the 3 sides of the chair seat board one by one.



- 2** Strengthen the positions shown in the diagram with nuts.



Use Instruction



1. Please use it on a flat, spacious floor.
2. Before using it, please check whether all parts are firm and whether the product is shaky and needs to be adjusted.
3. In the process of use, please check regularly or irregularly whether all parts are loose. If so, please tighten them in time.

Product Failure and Troubleshooting

Fault phenomenon: The desk and chair is shaking and unstable.

Cause analysis: The nuts are not tightened; the parts assembly do not fit.

Troubleshooting: Tighten the nuts, adjust the positions of parts, ensure desk and chair stable.

Maintenance

1. Avoid the direct sunlight and keep away from heat and fire sources;
2. Please wipe the stains on the surface of the desk and chair with a dry cloth. If necessary, you can use mild soap and detergent to clean. After cleaning with a soft wet cloth, dry it with a dry cloth;
3. Keep away from sharp objects from scratches and damage;
4. If not used for a long time, please keep it in a cool and dry place and cover it with a clean cloth or blanket (do not use plastic).

Precautions

- 1.The product is suitable for children aged 1 - 3 years.
- 2.Please use it under adult's guardianship. Children are not allowed to climb or trample on it, so as to avoid rollover and danger.
- 3.Keep away from fire and other strong heat sources.
- 4.Do not place it in water or on permeable ground.
- 5.Packaging materials are not toys. Please well keep them away from children.
- 6.Assembly is only allowed for adults. Please be careful and keep away from children when assembling.

The Charge Index of Harmful Substance Limit

Plastics	Phthalates Gross(DBP、BBP、DEHP、DNOP、DINP、DIDP)	≤0.1%
----------	-----------------------------------------------	-------

Warm Tips: Due to the process limitation, there may be some small black spots on the product, which is a normal phenomenon and does not affect the normal use.

After-sales Service

Product repair: please contact to service center of Costway Inc. or dealer.

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

THANK
YOU
😊