


f y @ **@**

Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana UK office: Ipswich AU office: Truganina





Contact Us !

Do NOT return this item. Contact our friendly customer service department for help first.



US:cs.us@costway.com UK:cs.uk@costway.com AU:cs.au@costway.com **USER'S MANUAL**

Kids Sand Box TS10040

COSTWAY



Before You Start

Please read all instructions carefully and keep it for future reference.

General Security Warning


Caution: The Product is not suitable for the children under 3 years Danger: Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard. Danger: Lack of attachment may cause a risk of tipping.


WARNING: CHOKING HAZARD-Small parts. Not for children under 3 years.

Warning for Assembly


- riangle Assembled only by adults
- \triangle Remove all Packaging, separate and count all parts and hardware.
- \triangle We recommend that, where possible, all items are assembled near the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.


 $\underline{\wedge}$ Ensure a secure surface during installation, and place the product always on a flat, steady and stable surface.






ASSEMBLY INSTRUCTIONS








9. Connect part J to part H and fix it with screw R. Note: Do not tighten screw R, which will lead to inflexible rotation of part J.

9

(x)_______ 6x90mm R x1



08

6x25mm

Q x4

8.Attach the

screws Q.

assembled two funnels onto part G,

and secure them with

09

