


#10493 Parts Breakdown



#10493 Replacement Part Numbers

Item	Description	QTY	Item	Description	QTY
1	Pad	1	11	Split Pin	9
2	Cotter Pin	1	12	Pin	3
3	Moving Tube	1	13	Connecting Bar	3
4	Spring Seat	3	14	Spring	3
5	Large Spring	3	15	Wheel	3
6	Ring	1	16	Pin	6
7	Chain	1	17	Pin	3
8	Lock Pin	1			
9	Main Tube	1			
10	Support Leg	3			