

CART - 500 - SCL

6/11/2009

Charging: Press the power switch down, while charging the light will stay red and once it is fully charged light will turn green.



Fig.1

Scale Turned off: Power Switch in the center
Scale Turned On: Power switch in up position

On/Off power switch



Fig.2

CALIBRATION

Turn on power switch on top of the panel, when scale is turned on, the screen will show "0" lb., if it doesn't show "0" please press CLR button to make the value "0".



Fig.3

MEASURING:

Put weight on the lift table and pump the cart up, LCD display will show object's weight.



Fig.4



Fig.5

DOT KEY:

To change the decimal press & hold Dot key, decimal will start shifting between the numbers.



Fig.6

CLR KEY:

Press clear key to zero the scale.



Fig.7

SET KEY

Press and hold down set key for couple seconds until 1st digit starts blinking.

1st digit is blinking



Fig.8

In Set mode, pressing the dot key will change the digits as shown below in Fig.9. Press dot key to increase the numbers.



Fig.9

Press Clear key to change input cursor to left.



Fig.10

Finally press set key to confirm the value.



Fig.11