



Acrylic Prism Cleaning Guide

The most frequent challenge with the use of acrylic is the use of incorrect cleaners. Never use cleaners containing ammonia. Cleaners such as Windex or 409 will harm your new acrylic item.

Use only products specifically recommended for cleaning acrylic.

A mild solution of dish detergent on a damp cloth can be used to remove dirt easily without harming the acrylic. You can also use Novus #1 or Brillianize.

Never use a dry cloth or your hand to clean your acrylic! This rubs the dirt and dust INTO the acrylic as much as it rubs it OFF. First, blow the dust or dirt off, or use a damp cloth to float the dust.

Acrylic is sturdy, however it is vulnerable to SHOCK. Dropping your acrylic can cause cracking.

If necessary, fine scratches can be removed with a mild abrasive polish such as Novus #2, or Novus #3.

Note: Acrylic Prism Bars can be returned to the manufacturer for re-polishing to provide many more years of service.