


BATTERY-FREE WIRELESS WALL SWITCH


Bluetooth Battery-Free Wireless Wall Switch – Single and Double Rocker

Single Rocker















For Use with Häfele Press to Pair and Connect Mesh Distributors

- > Battery-free, energy harvesting technology
- > Pressing the switch creates enough energy to transmit wireless signals to Häfele Bluetooth distributors
- > Traditional decora style works seamlessly with any home design
- > Replaces EnOcean switches 850.00.025 850.00.026
- > Can be flush mounted over a standard switch box or surface mounted directly to the wall

Surface Mount Wall wall switch box OR face switch back - 16 plate (5/8") OR (1/4")

> Functionality: On/Off

Dimming

Color Temperature Control

> Range: 10 m (30')

> Frequency: Bluetooth (BLE) 2.4 GHz

> H x W x D: 114 x 70 x 16 (4 1/2" x 2 3/4" x 5/8")

Material/Color: Plastic, white

Version	Item No.
Single Rocker Switch	850.00.940
Double Rocker Switch	850.00.944

Supplied With

Single or double rocker switch

Face plate

Back plate for surface mounting

Mounting screws

Note

Please order Häfele Press to Pair or Connect Mesh distributor separately.