

DIRECTIONS

- Slide battery cover ① out. Plug the 9V battery ② to battery connector. Insert battery to the compartment. Replace the battery cover ①.
- Choose the right bracket for your door. Insert the selected bracket ③ to the inlet hole ④. Save other bracket ⑤ for later use.
- Clip the doorknock device to the inside of any door. Switch the selector ⑥ to doorknock function. Knock on other side of the door to activate the unit.
- To use as a flashlight, slide down the selector ⑥ from OFF position

